

Above the Opening

by Travis Nech

Free edition — championbrickrepair.com

ABOVE THE OPENING

An Advanced Field Guide to Lintel Forensics, Load Paths, and Permanent Repairs on Complex Buildings — For Experienced Masons and Property Professionals

Travis Nech

© 2026 Travis Nech. All rights reserved.

ISBN pending KDP assignment

No part of this book may be reproduced, stored in a retrieval system, or transmitted in any form or by any means — electronic, mechanical, photocopying, recording, or otherwise — without the prior written permission of the author, except for brief quotations used in reviews or educational discussion.

This book is an educational field guide based on 50 years of hands-on field experience in masonry repair and lintel work across Texas. It is not a substitute for on-site evaluation of a specific building. Every structure, soil condition, wall assembly, and load condition is different. Where structure is involved — where loads are uncertain, where a wall is load-bearing, where steel has lost significant section, or where life safety is in question — hire a licensed structural engineer for that building and follow that professional's direction for that project. Use the methods in this book to read a wall more accurately, to ask better questions, to sequence work more safely, and to know where your experience ends and a structural engineer's review must begin.

Contents

Introduction: The Steel Nobody Thinks About — Until It Moves

Chapter 1: The Invisible Beam — What a Lintel Really Carries

Chapter 2: Rust Is a Jack — Corrosion, Expansion, and Section Loss

Chapter 3: Forensic Reading — Letting the Wall Testify

Chapter 4: Shelf Angles and Embedded Steel — The Failures You Cannot See

Chapter 5: Wide, Tall, and Heavy — Long Spans and Concentrated Loads

Chapter 6: Historic Lintels — Stone, Cast Iron, and Early Steel

Chapter 7: Shoring That Holds — Temporary Support and Safe Sequencing

Chapter 8: The Permanent Replacement — LintelLOCK on Complex Openings

Chapter 9: Water Above the Opening — Flashing Systems That End the Cycle

Chapter 10: Knowing the Line — When to Stop and Bring In a Structural Engineer

Chapter 11: Documenting, Bidding, and Defending Complex Work

Chapter 12: Failure Autopsies — Patterns Pros Learn to Prevent

Conclusion: Carry It Right, and It Carries for Good

Resources & Next Steps

About the Author

Introduction: The Steel Nobody Thinks About — Until It Moves

Every opening in a brick wall is a promise. Above every window, every door, every garage header, and every storefront, something has to carry the masonry that wants to fall straight down into that empty space. Most of the time that something is a piece of steel nobody sees, nobody paints, nobody inspects, and nobody thinks about — until it moves.

When it moves, the wall tells on it. A stair-step crack climbs away from a corner. A soldier course sags in the middle. A window that opened smooth for thirty years starts to drag at

the top. Mortar joints open on one side and pinch shut on the other. Owners call it settling. Tenants call it an old building. Experienced masons know better. They know to look above the opening first.

This book is for those masons. It is also for the contractors, property managers, facility directors, and serious property professionals who have already done the basic work — who have replaced a rusted residential lintel, repointed a cracked corner, or flashed a window head — and who now find themselves standing in front of buildings that do not behave like a simple house. Wider spans. Taller walls. Heavier loads. Multiple wythes. Stone over steel, steel inside concrete, shelf angles hidden behind brick that never shows its anchors until it fails. Buildings where the question is not just "is this lintel bad" but "what is this lintel actually carrying, where is that load going, and what happens to the rest of the wall if I take it out wrong?"

That is forensic work. Not forensic in the courtroom sense, though documentation matters and Chapter 11 will cover it in full. Forensic in the field sense: reading evidence in the order it was left, separating cause from symptom, and refusing to repair the crack while leaving the force that made the crack still at work in the wall.

After 50 years of hands-on field experience in Texas — from single-story ranch homes in Fort Worth to multi-story commercial brick in Dallas, from historic storefronts in small Hill Country towns to apartment complexes that have been patched three times by three different crews — the pattern is consistent. Lintel failures are rarely sudden and they are rarely mysterious. They are slow, they are readable, and they are almost always made worse by water that was allowed to sit where it never should have sat. Rust builds. Steel expands. Brick lifts, cracks, and shifts. A repair that only addresses the visible masonry without addressing the steel and the water will be back. Usually sooner than anyone wants to admit.

The basic books in this field teach the starting skills: what a loose lintel is, how to support a simple opening, how to set a replacement and tool a clean joint. Those skills matter, and if you have not mastered them, master them first. This book assumes them. What it adds is the layer that separates a competent repair from a permanent one on a complex building: load paths, forensic reading, shoring and sequencing under real weight, historic materials that punish modern assumptions, flashing systems that end the corrosion cycle instead of resetting its clock, and the professional judgment to know when a job needs a structural engineer at the table before a single brick comes out.

A word about scope and honesty. I am a mason and a field

practitioner. My authority in these pages is 50 years of hands-on field experience — looking at walls, taking them apart carefully, putting them back to carry right, and coming back years later to see what held and what did not. I am not a licensed engineer, and this book does not pretend to be an engineering manual. Where loads need calculation, where a wall system is unusual, where a change in use has added weight the original builder never planned for, I will tell you plainly to bring in a structural engineer for that building. That is not a disclaimer tucked in to cover the author. That is part of the craft. The best field professionals I know are not the ones who claim they can handle everything. They are the ones who know exactly where the line is and who stop on the right side of it.

Texas context runs through this book because Texas built a particular kind of masonry stock, and it ages in particular ways. Expansive clay soils from the Blackland Prairie through much of North and Central Texas move foundations seasonally, and that movement shows up at openings first because openings are where a wall is weakest. Summer heat drives moisture cycles hard. Winter freezes are fewer than up north, but a single hard freeze on a saturated wall can spall brick faces and split mortar that looked sound in October. Much of the postwar commercial and multifamily stock across the Dallas-Fort Worth Metroplex was built fast, with shelf angles and lintels that received minimal protection from the weather and flashing details that depended on sealant more than on metal and gravity. Forty and fifty years later, that stock is all coming due at once. If you work in Texas, you are seeing it. If you work in similar soils and similar building stock elsewhere, you will recognize it.

The chapters ahead follow the order a good forensic job actually follows. Chapters 1 and 2 rebuild the fundamentals at an advanced level: what a lintel truly carries, how arching action changes the load, and exactly how corrosion works as both an expanding jack and a thinning, weakening process at the same time. Chapter 3 gives you a field method for reading a wall — measurements, photographs, crack mapping, and probing — before you price or touch anything. Chapters 4 through 6 take on the hidden and the difficult: shelf angles and embedded steel, long spans and concentrated loads, and historic lintels in stone, cast iron, and early steel. Chapter 7 covers shoring and sequencing, the unglamorous work that keeps people safe and walls standing while the permanent work happens. Chapter 8 covers permanent replacement on complex openings, including the field-developed LintelLOCK system — his field-developed system for locking a replacement lintel into a lasting, properly supported installation — and when a standard replacement is, and is not, enough. Chapter 9 is about water, because no lintel chapter is complete without it: flashing above the opening is what

decides whether your new steel lasts fifteen years or fifty. Chapters 10 and 11 cover professional practice — the engineer line, and documenting, bidding, and defending complex work so you get paid fairly and your work stands up to scrutiny. Chapter 12 closes the technical arc with failure autopsies: composite patterns drawn from common field failures, each explicitly presented as a teaching pattern, so you can learn the lesson without paying the tuition on your own job.

Every example in this book that describes a specific building or job is labeled for what it is. A hypothetical example is an invented teaching scenario. A composite example combines details from several real-world patterns into one illustration without naming any customer or property. There are no named customers in this book and no stories presented as a specific client's job. That is deliberate. The lessons are real. The privacy is also real.

Read this book with a tape, a level, and a notebook in mind. The goal is not that you finish it feeling impressed. The goal is that the next time you stand under a cracked opening on a complex building, you see more than the last crew saw — you see the load, the water, the rust, the history, and the sequence that fixes it for good.

Above the opening is where the wall keeps its secrets. Learn to read them, carry the load right, and the wall will carry for good.

Chapter 1: The Invisible Beam — What a Lintel Really Carries

The Triangle Above the Opening

Ask a new hand what a lintel carries and he will point at all the brick above the window, from the head of the opening straight up to the roof. It is a reasonable guess and it is usually wrong — and understanding why it is wrong, and when it stops being wrong, is the foundation of everything else in this book.

Masonry, laid well with sound mortar, does not behave like a stack of loose bricks. It behaves, within limits, like a solid panel that can arch. When you cut an opening in that panel and set a lintel across it, the masonry above tends to form a natural arching zone — commonly described in the field as a triangle rising from the ends of the lintel at roughly 45 to 60 degrees, meeting near the center above the opening. Brick inside that triangle is the brick the lintel truly has to support

as a direct load. Brick outside and above that triangle is largely carried by the wall itself, transferred sideways and down around the opening through arching action, provided the masonry is sound, the mortar bonds are intact, and there is enough wall on each side of the opening to receive that thrust.

That single idea changes how you size, shore, and price a job. A four-foot residential window in a one-story wall may put only a modest triangular wedge of brick on its lintel. The steel still needs to be sound, properly seated, and protected from water, but the load is limited and forgiving. Now take the same four-foot width and put it on the first floor of a three-story building with deteriorated mortar, a second opening close beside it, and a concrete floor system bearing on the wall just above. The triangle does not form cleanly. Arching action is compromised by weak mortar and by the neighboring opening cutting into the wall that would receive the thrust. A concentrated load from above lands inside the zone. Suddenly that same width of opening is carrying a very different burden, and a lintel choice that was fine on the ranch house is undersized and under-supported here.

Field rule: never judge a lintel by the width of the opening alone. Judge it by width plus height of wall above, condition of the mortar, distance to the nearest other opening or corner, and anything bearing on the wall from floors, roofs, signs, canopies, or equipment. The opening is the location. The load path is the job.

Hypothetical example: A property manager asks for a price to replace a rusted lintel over a six-foot storefront door on a two-story brick building. Over the phone, it sounds like one lintel, one day. On site, you find a second-story floor joist pocket bearing in the wall almost directly above the center of the opening, a heavy parapet above that, and mortar on the first floor so soft you can rake it with a screwdriver. The triangle that should have reduced the load never fully formed because the mortar could not hold the arch. The lintel has been carrying far more than the door width suggests, it has deflected, and the crack pattern in Chapter 3 terms confirms it — wide at the center, stepped at both ends. Pricing that job as a simple swap would lose money and, worse, would put a new lintel back into the same overloaded condition. The forensic answer is shoring that picks up more wall, a stronger replacement section, attention to bearing at both ends, and a conversation about the mortar condition across that elevation before any number is final.

Bearing, Deflection, and the Ends of the Beam

A lintel is a beam, and every beam lives or dies at its ends. In masonry work the ends are the bearing points — the length of steel that rests on sound masonry at each side of the opening. Common field practice for simple residential work calls for a minimum bearing length at each end, and complex work often needs more, on masonry that is verified sound, not assumed sound. Rust does not respect that distinction. It is common to open a wall and find that the visible center of a lintel looks passable while the last few inches at each bearing are thinned, laminated, and crumbling — exactly where the load transfers into the wall. The beam was failing where nobody could see it.

Get in the habit of probing the ends first. With the owner's permission and proper support in place where needed, expose enough to see and feel the bearing zones. Sound steel rings and resists a pick. Deteriorated steel flakes in layers, powders, and lets a screwdriver sink into laminated rust. Document what you find with photographs and measurements — the length of good bearing remaining is a number that matters for the repair plan and for the bid defense in Chapter 11.

Deflection is the second fact at the ends and the center together. Steel bends under load, and a small amount of elastic bend is normal. What you are looking for is permanent sag — a lintel that stays bowed when you sight along it, brick courses that dip toward the center of the opening, a window or door frame racked out of square by the movement above it. Measure it. A straightedge or a taut string line across the opening, with the dip measured at center in fractions of an inch, turns an opinion into a record. A sixteenth of an inch on a short residential lintel may be an old, stable condition worth monitoring. A half inch of sag on a long commercial lintel with active cracking is a different conversation entirely, and it changes the shoring plan in Chapter 7 because a sagged wall has already redistributed its loads in ways you must support before you disturb them.

Also read the masonry at the bearing points for crushing and rotation. Spalled brick, crushed mortar, or a bearing block tilted under the load tells you the transfer is failing even if the steel at center looks acceptable. On complex buildings, check whether the lintel bears on solid masonry, on a hollow or deteriorated backup, or — worst of all — on a previous repair that was never structural to begin with. Crews before you may have set steel on loose brick, on wood blocking, or on a bed of mortar with nothing solid under it. You inherit their shortcut the moment you disturb the wall, so find it during diagnosis, not during demolition.

When Arching Action Fails

Arching action is a gift, but it has conditions, and advanced work means knowing the conditions cold. It needs sound mortar with real bond. It needs height — enough masonry above the opening for the arch to form before the wall is interrupted by a floor, a roof, another opening, or the top of the parapet. It needs abutment — enough solid wall on each side to absorb the sideways push. Take any one of those away and the lintel's real load climbs, sometimes dramatically.

Short wall height above an opening is the most missed condition in the field. A lintel placed just below a floor line, a roof bearing, or the top of a parapet may have only a few courses above it. There is no room for a triangle to form. That lintel carries nearly everything directly above it, course by course, plus whatever the floor or roof delivers. Storefront heads tucked under a sign band, garage openings in a wall that tops out quickly, and top-floor windows on a multi-story building all live in this category. Treat them as full-load lintels regardless of how narrow the opening looks.

Close openings are the second missed condition. Two windows separated by a narrow pier of brick share that pier as their abutment. If both lintels are deteriorated and the pier itself has cracked or its mortar has failed, neither opening arches properly and the pier becomes a loaded column of questionable strength. Replacing one lintel at a time without supporting and assessing the shared pier is how a one-window job becomes a two-window emergency. On multifamily and office buildings with rhythmic, closely spaced windows, think in terms of the whole elevation, not one opening at a time.

Vertical cracks directly above the center of an opening, rather than stepped cracks at the corners, are another clue that arching is not happening and the wall is behaving more like two separate panels hanging on the steel. Likewise, a horizontal crack running along a bed joint just above the lintel line, extending well past the opening on both sides, often marks the line where shelf angle or lintel movement has lifted or shifted an entire wythe — a condition Chapter 4 covers in depth. Learn to let the crack pattern correct your load assumptions. The wall is always telling you whether your triangle theory matches its reality.

Composite example: A three-story apartment elevation shows identical windows stacked floor over floor. The first-floor lintels are heavily corroded and the brick above them is stepped-cracked at the corners, as expected. But the second-floor lintels, which look cleaner from the ground, show a fine vertical crack above the center of each opening and frames that bind at the top corners. On closer inspection with a lift, the second-floor openings sit just below the third-floor joist bearing line, with limited masonry height to form an

arch, and each lintel is picking up a share of floor load the original detail never isolated. The visible rust was worse downstairs; the load problem was worse upstairs. A crew that priced only what rusted most would have missed the structural story entirely. That is why load reading comes before rust reading in a proper survey, even though rust is what usually gets the phone call started.

Concentrated Loads and Load Path Interruptions

Uniform brick weight is predictable. Concentrated loads are where complex buildings separate from simple ones. A concentrated load is any heavy point or line delivered into the wall at a specific place: a steel beam pocketed into the masonry, a floor or roof joist bearing, a column above that lands over an opening below, a heavy sign, canopy, or awning bracketed back to the wall, rooftop equipment whose curb bears near an opening, or even a later remodel that hung a new load on an old wall. If that concentration falls within or near the zone above your lintel, your lintel may be carrying it — whether or not anyone designed it to.

Trace load paths the way water paths get traced in Chapter 9: from the top down, without skipping a floor. Start at the roof. What bears on this wall — joists, trusses, a parapet, equipment? Move down a level. Where do floor systems bear? Are there beams or columns inside that deliver load to this elevation? Has the building's use changed — a warehouse turned into offices, a retail space turned into a restaurant with heavier rooftop equipment, apartments whose balconies were enclosed and added weight at the wall line? Every addition is a load path interruption or addition that the original lintel never agreed to.

Openings cut later are another interruption pros must hunt for. A new door cut into an old wall, a window widened for a storefront, a louver or vent opening added for mechanical equipment — each one steals abutment from its neighbors and redirects load onto lintels that were sized for a different wall. Look for the scars: brick that does not match, mortar that does not match, a steel plate or angle that looks newer than everything around it, toothing that was never done and a straight vertical joint where the cut was filled. Buildings accumulate these edits over decades, and no set of drawings, if drawings even exist, keeps up with all of them. Your eyes on the wall are the updated drawing.

The practical takeaway of this chapter is a short discipline you can run at every complex opening. One, estimate the triangular load, then list every reason the real load may be higher — poor mortar, short height above, close openings or

corners, concentrated loads, changed use, later cuts. Two, verify bearing at both ends with your own eyes and tools. Three, measure deflection and record it. Four, decide whether the load picture is clear enough to proceed on field experience or cloudy enough to need a structural engineer before demolition. That fourth step is not hesitation. It is the mark of the advanced practitioner this book is written for, and Chapter 10 will give you the full framework for it.

Carry the load in your head first, accurately, and every later decision — shoring, steel, flashing, price — gets easier and safer. Guess at the load, and you will be guessing at everything else all the way to the final joint.

Chapter 2: Rust Is a Jack — Corrosion, Expansion, and Section Loss

How Rust Lifts a Building

Most people think of rust as weakening. It does weaken, and the second half of this chapter covers that loss in detail. But the first thing rust does in a masonry wall — the thing that cracks brick, opens joints, and bows wythes outward long before a lintel actually collapses — is expand. Rust is a jack. It lifts, pushes, and splits with slow, patient force that no mortar joint can resist.

The chemistry, in plain field terms, is simple. Steel is iron refined into a strong, useful form, but given water and oxygen it wants to return to iron oxide — rust. The critical fact for a mason is volume. The oxide that forms occupies substantially more space than the steel it came from. Field references commonly describe the expansion as several times the volume of the original metal, and the exact multiple matters less than what your eyes see on the wall: a thin layer of steel, corroding in a confined space between brick and mortar, becomes a thick, laminated mass of rust that has nowhere to go. So it pushes. It pushes up against the brick above, out against the wythe in front, and down against the bearing below. Masonry is strong in compression across a broad area and weak against a concentrated prying force along a joint. The rust wins, every time, given enough water and enough seasons.

That is why lintel corrosion damage so often looks like the wall was lifted. Because it was. Look for the signature: a horizontal crack along the bed joint at the lintel line, brick courses above the opening bowed slightly outward compared with the wall beside it, mortar joints opened at the top of the

steel and pinched elsewhere, and corner cracks stepping away as the lifted section tries to separate from the wall that did not move. On shelf angles running long distances, the same jacking can lift or shift an entire wythe for dozens of feet, which is why Chapter 4 treats shelf angles as a system, not a detail.

The jack works in cycles. Water enters — through a failed joint, a missing or damaged flashing, a cracked coping, a gutter that overflows onto the wall — and wets the steel. Corrosion advances and expands. The expansion opens the joint a fraction wider. The wider joint admits more water next rain. In Texas, add summer heat baking moisture through the wall, hard driven rain from Gulf weather pushing water into joints that would shed a gentle rain, and in winter the occasional freeze expanding trapped water further. Each cycle is small. Ten years of cycles will move a wall measurably. Thirty years will move it unmistakably.

Understanding rust as a jack changes how you talk to owners. You are not describing a cosmetic stain. You are describing an active force still at work inside their wall, one that will continue after a pointing crew seals the visible cracks if the steel and the water source are left in place. Repointing over an actively jacking lintel is one of the most common wasted repairs in this trade. The new mortar is harder than the old, the rust keeps expanding, and the next crack often steps into the brick itself because the joint can no longer give. You will see that failure pattern in the autopsies in Chapter 12.

Section Loss — The Other Half of the Damage

While rust expands outward, it consumes inward. Every layer of oxide that jacks the wall is steel that is no longer steel. The lintel gets thinner, weaker, and less able to carry its load at the same time it is actively prying the wall apart. That double action — more force against the wall, less strength in the member — is why advanced assessment always measures both displacement and remaining section.

Section loss is not uniform, and its location matters as much as its amount. A lintel is a beam: its strength lives disproportionately in its flanges and in the full depth of its section, especially near the center where bending is greatest and at the bearings where load transfers out. Common lintel shapes in the field include loose steel angles set under the outer wythe, shapes built into the wall, and on older work, early structural sections whose exact profile you may have to measure to understand. An angle that has lost much of its horizontal leg to laminated rust has lost its seat for the brick. An angle whose vertical leg is thinned and holed has lost

bending strength. Loss concentrated at a bearing shortens effective support. Teach your eye to ask not just "how much rust" but "rust where, on which leg, and how much sound metal remains at center and at each end."

Field assessment uses simple tools honestly. After safe exposure, clean a small test area down to sound metal with a wire brush or scraper — never grind aggressively and call the thinned result original thickness. Measure remaining thickness with calipers where you can reach an edge. Probe with a pick and a hammer: sound steel is hard, continuous, and rings; advanced deterioration flakes in sheets, crumbles at the edges, and sounds dull. Photograph the cleaned test spot beside a tape so the record shows scale. On complex or high-load openings, if remaining section is in genuine doubt, that doubt itself is the finding — record it and bring in a structural engineer to evaluate the member rather than guessing at a percentage and building a bid on the guess.

Distinguish surface corrosion from structural corrosion, because owners and even some contractors conflate them in both directions — panic over light surface rust that a proper cleaning, protection, and flashing correction can address in place where the design allows it, and complacency over deep laminated loss hidden behind a painted face. The visible face of a lintel at the wall line is the least reliable indicator of its condition. Steel often looks worst at the exposed drip edge and is in fact sound behind it, or looks acceptable at the face while the concealed top leg and bearing ends — where water sits longest — are severely wasted. Exposure and probing settle arguments that photographs from the ground cannot. Build your survey scope to include that exposure on any job where replacement-versus-retention is a real financial decision.

One more form of loss deserves its own warning: corrosion at fasteners, anchors, and ties. On shelf angles and on lintels that are anchored back into backup or structure, the connectors can waste faster than the main member because they are smaller, wetter, or of a different metal. A lintel or angle that still measures adequately can still be failing as an assembly if its anchorage is gone and the wythe it supports is held mostly by habit and friction. When you expose an assembly, inspect the whole assembly.

Water Is Always the First Cause

No chapter on rust is honest without stating the rule that governs this entire book: steel in a dry wall lasts a very long time; steel in a wet wall is on a clock. Almost every advanced lintel failure you will diagnose traces back to a water management failure above or at the opening — failed or missing flashing, open head joints, deteriorated mortar,

cracked or displaced coping, failed sealant at a joint that should never have depended on sealant alone, roof or gutter discharge onto the wall, or grading and paving changes that splash and drive water where the original design kept it away.

That means your forensic survey must always travel up. From a damaged lintel, follow the wall above it to every place water can enter: the next flashing line up, the parapet and its coping, window heads and sills stacked above, movement joints whose sealant has failed, penetrations for signs, lights, and conduits. Owners want a price for the crack they can see. Professionals find the entry point two stories above that has been feeding the crack for a decade. Chapter 9 details the flashing systems that end the cycle, but the diagnostic habit belongs here: never quote a permanent steel repair without a stated plan for the water that destroyed the last steel. New steel in an old wet detail is not a permanent repair. It is a reset of the same clock, and saying so plainly, in writing, in the bid, is part of defending complex work in Chapter 11.

Hypothetical example: A facilities director shows you a ground-floor lintel replaced only nine years earlier, already showing rust bleed and a reopened horizontal crack. The replacement steel itself, where you expose it, is not yet badly wasted — but it is wet, and a hands-width above it the original work left no through-wall flashing and no weeps, with a hard sealant joint at the wall face trapping moisture behind the brick. The first replacement treated the symptom. The wall stayed wet. The second repair, scoped correctly, includes opening enough courses to install a proper flashing system with end dams and weeps, correcting the joint above, and only then addressing the steel. The steel line item is smaller than the water line item, and the report says why — because on that building, water was the disease and rust was the symptom.

Also hunt for interior water. On complex buildings, plumbing, condensate lines, and roof drains routed inside walls can wet lintels and shelf angles from behind, producing corrosion with no obvious exterior entry. Stains on interior finishes aligned with an opening, corrosion worse at one end than the other, or damage isolated to a single bay while identical bays stay sound are all prompts to ask what is inside that wall before assuming weather did it. A repair that stops exterior water while a slow condensate drip continues will fail on schedule.

Reading Rust Stains and Predicting What Is Hidden

Before any exposure, the wall face itself offers a corrosion preview — if you know how to read stains rather than merely notice them. Rust bleed weeping from a bed joint at the lintel

line, staining that fans downward from the bearing ends, blistered or lifting paint on exposed steel, and efflorescence patterns near an opening all carry information. Heavy staining at one end and little at the other suggests water is arriving or pooling unevenly — check slope, flashing laps, and the nearest downspout or scupper before you assume uniform deterioration. Staining that appears well above the lintel you were called about often points to a shelf angle or embedded steel higher in the wall, bleeding down. Follow stains up to their highest point of origin, not down to where they become most visible.

Use stain reading to plan exposure efficiently. On a large elevation with many openings, rate each opening from the ground first — displacement, cracking, staining, frame condition — then expose the worst, a middle case, and an apparently sound case for comparison. That three-point sample tells you whether you are dealing with an isolated failure or a systemic condition at the end of its service life across the whole elevation, which is a fundamentally different scope, price, and conversation with the owner. Systemic end-of-life corrosion on a complex building is not twenty separate small jobs. It is one program, best phased by elevation and risk, and presenting it that way is more honest and, in the long run, more profitable than selling the same emergency twenty times.

Composite example: On a multi-wing school building, one wing's window lintels show heavy jacking cracks while the other wing, built in the same year with the same details, shows only light staining. The difference, found on the roof, is unglamorous: the damaged wing's gutters overflow at two joints and its coping joints have opened, wetting that elevation in every significant rain, while the other wing sheds cleanly. Same steel, same age, same climate — different water. The repair program correctly spends money on gutters and coping for the whole building first, then phases lintel replacement by measured section loss rather than by which wing complained loudest. That is forensic thinking applied to rust: treat the force, measure the loss, sequence by risk.

Close this chapter with the working standard it sets for the rest of the book. Every lintel assessment will state three things separately: how much the rust has moved the wall, how much sound steel remains and where, and where the water is coming from. If any one of the three is unknown, say it is unknown and state how you will find out. A mason who can deliver those three answers clearly — with measurements and photographs — is already doing advanced work, before a single brick is removed.

Chapter 3: Forensic Reading — Letting the Wall Testify

Start Wide, Then Narrow

Forensic reading is a discipline of order. Start with the whole building, narrow to the elevation, then to the bay, then to the opening, then to the joint. Crews who start at the crack miss the roof drain pouring onto the wall two floors up. Crews who start at the building almost never miss it, because they walked the roofline, the grade, and every elevation before they ever set a ladder at the damaged opening.

Begin with a slow exterior pass. Note the building's age clues, construction type, number of wythes if you can determine it, additions and alterations, and any change of use that added load or water. Photograph each elevation whole, then each bay, before close photographs begin — context photographs are what let you, an owner, or a structural engineer reconstruct the story months later. Record compass orientation: a south or west elevation in Texas takes brutal sun and driven weather differently than a sheltered north wall, and identical details age at different rates on different faces. Note trees, grade, paving, irrigation, and drainage against the wall. Sprinklers wetting brick daily will write themselves into your lintel findings, and no flashing system fully compensates for a wall that is watered like a lawn.

Then narrow. At the elevation, map every opening and every crack, even the ones you were not called about. Patterns emerge at elevation scale that are invisible at single-opening scale: cracks that repeat identically at every floor point to a systemic detail; damage isolated to one stack of openings points to a localized water path down that stack; damage that worsens toward one end of the building raises questions about movement — including foundation movement, which in Texas clay soils is a real and common contributor. Where foundation movement is part of the picture, remember the division of work honestly: masonry above an opening is your craft, and where a foundation itself needs a system, the proven field approach discussed in this book's resources is pressed concrete piles — and, more importantly, a foundation question that affects the whole structure is another prompt to involve the right specialist rather than stretching a lintel scope to cover it.

Carry a simple kit and use it every time: tape and a folding rule, a four-foot level and a string line, a torpedo level for sills and heads, a crack comparator card or a ruler you photograph in frame, calipers, a wire brush, a pick and a masonry hammer, a moisture meter if you own one, a flashlight, a

mirror for looking up into cavities, marking chalk and painter's tape, and a notebook that will survive the job box. None of this is exotic. The difference between a guess and a forensic reading is rarely the tool. It is whether measurements were actually taken and written down.

Crack Mapping — The Wall's Own Report

Cracks are the wall's testimony, and like any testimony they need to be recorded precisely and interpreted carefully. A crack map is a simple elevation sketch — hand-drawn is fine — showing each opening, each crack's location, direction, approximate length, and width at its widest point, plus the date. Add arrows where you can determine direction of movement and notes where joints have opened, closed, or displaced out of plane. That single page, done carefully, will outperform a folder of uncaptioned phone photographs in every later conversation about scope and price.

Learn the common dialects. Stepped cracks running diagonally away from the upper corners of an opening, following mortar joints in a stair pattern, are the classic signature of lintel deflection and corrosion jacking at that opening — load that should arch is instead dropping or being lifted unevenly at its support. Vertical cracks above the center of an opening suggest the wall above is splitting because arching did not form or the support below sagged at mid-span. Horizontal cracks along the bed joint at the lintel or shelf angle line, especially when they run past the opening, speak of expansion jacking along the steel line or movement of a whole wythe. Cracks that are wider at the top than the bottom, or the reverse, tell a direction story about rotation — which end, or which face, is moving. Out-of-plane displacement, where one side of a crack sits proud of the other, is a more serious dialect still: the wythe is not just splitting, it is shifting, and shoring and sequencing in Chapter 7 must account for it before demolition releases what friction is still holding.

Equally important is deciding which cracks are active. Old, stable cracks wear their age: dirt and paint lines continuous across them, mortar patches from prior repairs that have themselves aged without re-cracking, edges softened by weather. Active cracks look fresh — sharp edges, clean faces inside the split, prior patches re-cracked along the same line, sealant torn rather than merely aged. Where timing and budget allow, simple tell-tales help: a dated pencil line across a joint, a small dab of brittle material bridging a crack that will split if movement continues, or a proper crack monitor on significant work. Record the observation method and date so a later visit converts an argument into a comparison. Never declare a crack stable from a single visit unless the age evidence is unmistakable. Say "no evidence of recent

movement observed on this date" — accurate, defensible, and honest.

Separate masonry movement at openings from broader structural movement by checking references beyond the wall: door and window operation throughout the area, floor levelness where you have access, cracks in interior finishes aligned with exterior ones, and separation at additions or at junctions between different construction types. Your scope is the wall and its openings, but your report should flag patterns that exceed that scope. An owner is better served by your honest note — "pattern suggests building movement beyond the lintel scope; recommend structural engineer review" — than by a confident lintel bid laid over a moving building.

Hypothetical example: You are called for one cracked opening at a medical office. Your elevation map, done before quoting, shows the same corner-step pattern, fainter, at four other openings on that face, a horizontal line developing at the shelf angle above, and interior door binding on the same side of the building. The honest scope conversation changes completely: this is an elevation program with a possible movement component, not a one-opening repair. The owner may still choose to phase the work — worst opening first, with monitoring on the rest — but that choice is now informed, documented, and yours to defend. The map took forty minutes. It changed a small, doomed job into a correct, phased one.

Probing, Sounding, and Careful Exposure

What the surface hides, your hands must find — within permission, with support where support is needed, and with the discipline to stop opening when opening itself could release a compromised section. Probing and exposure are where forensic reading becomes physical, and where inexperienced crews do accidental demolition. Plan every exposure as if the steel inside is worse than you hope, because sometimes it is, and the wall section above it may be relying on the very material you are about to disturb.

Sounding comes first and costs nothing. Tap along courses above an opening and along bearing zones with a hammer, listening for the difference between solid, well-bonded masonry and hollow, delaminated, or detached sections. A wythe separated from its backup by corrosion jacking or failed ties often sounds drummy well beyond the visible crack. Mark sounded boundaries in chalk; the hollow map is part of the record and part of the shoring plan, because a detached wythe needs support and handling that a bonded wall does not.

Next, mortar assessment. Rake a small sample joint with a

screwdriver or pick at several points — at the opening, and at a control point on sound wall away from damage. Mortar that powders, crumbles in depth, or can be excavated with light hand pressure cannot be counted on for arching action, cannot hold new work to the standard the job assumes, and changes both load reading from Chapter 1 and repointing scope. Note mortar condition in plain grades — sound, weathered at surface only, or deteriorated in depth — at each location tested. Also note prior repointing: hard, incompatible mortar smeared over soft original joints is a common aggravator that traps moisture and forces movement into the brick, and you will inherit its consequences if your scope does not name it.

Exposure, when authorized, should be minimal, targeted, and immediately useful: remove the smallest number of units needed to confirm steel section and bearing at the locations Chapter 2 identified — a bearing end and, where reachable, a mid-span look — plus a check of flashing presence and condition above the steel. Photograph each stage before, during, and after, with a tape in frame. Measure and record remaining steel thickness, bearing length on sound material, presence or absence of flashing, weeps, and end dams, and the condition of backup and ties in the opened zone. Then close the exposure weather-tight the same day unless the full repair follows immediately under proper shoring. An open forensic cut left for weather undoes the professionalism that made it.

Know the stop conditions for probing cold. If sounding shows a large detached area, if bearing masonry crumbles under light probing, if an opening's frame is carrying visible load because the lintel above it has effectively failed, or if any condition suggests a section could drop when disturbed — stop, make the area safe, shore under a competent plan, and escalate the conversation to include a structural engineer before further disturbance. Finding the limit of safe investigation is not a failed survey. It is a successful one. It is exactly the testimony the wall needed you to hear.

Photographs, Measurements, and the Written Record

A forensic reading that lives only in your memory will lose every argument it ever meets — with an owner who remembers the price differently, with a later crew who claims your work caused their crack, and with your own future self returning to phase two of a program a year later. The record is not paperwork for its own sake. It is the deliverable that makes complex work defensible, biddable, and repeatable, and Chapter 11 builds the business side of it. This section sets the field standard.

Photograph in a fixed sequence so nothing is skipped under pressure: whole elevation, bay, opening front-on, each corner and bearing zone, the head and sill conditions, interior side where accessible, roof and drainage features above, then detail shots with scale. Shoot front-on as well as at an angle — angled light reveals bowing and out-of-plane shift that a flat front photograph hides. Include the tape, level, or string line in the frame for every measurement you claim. A photograph of a sagging course means little; a photograph of a string line with a measured half-inch dip at center, dated, is evidence.

Write measurements as numbers, not adjectives. Span of opening, bearing length each end, remaining steel thickness at each probed point, deflection at center, crack width at widest point and at the ends, joint opening at the steel line, out-of-plane offset if any. Adjectives like "bad," "heavy," and "severe" belong in summaries, never in place of the numbers beneath them. Add weather and recent rain history where you know it — a wall read the morning after a storm tells a wetter story than the same wall in a dry month, and moisture observations should carry that context.

Close every survey with a one-page field summary written the same day: what was inspected, what was found in the three Chapter 2 terms — movement, remaining section, water source — what remains unknown, and what you recommend next, including any recommendation for a structural engineer and why. Distinguish clearly between observed fact, field judgment based on 50 years of hands-on field experience patterns like those in this book, and items requiring testing or another professional's evaluation. That three-way honesty is what separates a forensic report from a sales document, and owners of complex buildings — the clients worth keeping — can tell the difference on one reading.

Composite example: Two contractors look at the same bowed, cracked elevation on a retail center. The first describes it as "a bunch of bad lintels" and prices a per-opening swap. The second delivers an elevation crack map, a table of measured deflection and remaining section per opening, photographs with scale, a note identifying the failed parapet coping as the common water source, and a phased plan that fixes the coping first. The second contractor's total program costs more and wins anyway, because the owner can finally see the building the way the wall has been showing it for years. Price did not win that job. Reading did.

You now have the three-part foundation of this book: carry the load in your head, name the rust honestly, and let the wall testify before you touch it. The chapters that follow apply those habits to the hidden steel, the heavy spans, the historic work, and the permanent repairs that complex buildings demand.

Chapter 4: Shelf Angles and Embedded Steel — The Failures You Cannot See

Most lintel failures announce themselves. A crack steps up from a corner. A header sags. Brick slips. You can see the problem, measure it, and plan a repair.

Shelf angles and embedded steel are different. They fail in the dark, behind the veneer, where water has been working for years before the first outward clue appears. By the time the wall tells you something is wrong, the steel that was supposed to carry it may have lost a third of its thickness, expanded to several times its original volume, and lifted or split the masonry it was hidden inside.

This chapter is about learning to read what the surface is trying to tell you, understanding what is actually happening behind it, and knowing when the only honest next step is to open the wall and look.

What a Shelf Angle Is Really Doing

On a multi-story brick veneer building, the veneer cannot carry itself from the ground to the roof in one continuous stack. The weight would be too great, movement would be unmanageable, and the foundation ledge would have to carry more than it should. So the wall is broken into vertical sections. At intervals — often at each floor line, sometimes every two floors — a horizontal steel angle is anchored to the structure behind the veneer. One leg of the angle bolts or welds to the frame or the slab edge. The other leg sticks out, forming a small shelf. The brick above sits on that shelf. The brick below stops just short of it, with a soft joint in between.

That is the shelf angle, also called a relieving angle, because it relieves the masonry below of the weight above. Each shelf carries only its section. When the system works, loads stay predictable, movement joints stay where the designer put them, and the wall ages evenly.

Embedded steel shows up in older construction in other forms as well: steel lintels built right into the wall over openings, steel channels tying wythes together, reinforcing bars in grouted cells, and angles or plates cast into parapets and cornices. The principle is the same. Steel inside or behind masonry is doing structural work that the masonry alone was not expected to do.

The trouble is that steel and masonry live by different rules. Brick and mortar are porous. They absorb water, hold it for a while, and give it up slowly. Steel, when it stays wet and has access to oxygen, rusts. Rust does not just thin the steel. It expands. Corrosion products can occupy six to ten times the volume of the steel they came from. Inside a confined wall, that expansion has nowhere to go. It pushes. It lifts brick courses. It splits mortar joints. It cracks the veneer from the inside out, in a slow, steady jacking action that no sealant on the surface can stop.

That is why a shelf angle problem is never just a steel problem. It is a water problem first, a steel problem second, and a masonry problem by the time you see it.

Hypothetical example: A four-story office building in North Texas, built in the late 1980s, shows a horizontal crack running almost the full length of the south elevation, right at the third-floor line. The crack is wider in the middle of the elevation than at the corners, and the brick course above it has lifted slightly, enough that the mortar joint below is open and the soft joint sealant has pulled away. Nothing about the pattern looks like settlement. Settlement does not run in a straight horizontal line at a floor level. That line is telling you exactly where the shelf angle sits — and that something at that line is pushing up.

Reading the Surface Clues

Experienced eyes learn a short list of clues that point behind the wall.

The first is rust staining. A faint orange-brown wash below a joint, streaks running down from weep holes, or staining that keeps coming back after cleaning all suggest steel is corroding nearby. Staining alone does not prove section loss, but it proves water and steel have been in contact for a while.

The second is displacement at a floor line. Look along the elevation with your eye close to the wall, sighting down its length. A shelf angle that is jacking will often show as a course that has moved outward or upward relative to the courses below. The movement may be only an eighth of an inch. On a long elevation, an eighth of an inch out of plane is easy to spot when you sight along the wall and almost impossible to see standing square in front of it.

The third is a pattern of vertical cracks spaced at regular intervals. As a corroding angle expands along its length, it does not push evenly everywhere. It pushes hardest where corrosion is worst and where anchorage restrains it. The veneer responds with vertical cracks at repeating spacing, often near the angle's anchor points or at changes in the

backup structure.

The fourth is failed soft joints. The horizontal joint under a shelf angle is supposed to stay compressible so the structure can deflect and the veneer can move without crushing. When that joint is packed hard with mortar droppings from construction, filled with rigid material during a later repair, or simply squeezed closed by expanding steel, the wall loses its relief point. Crushed sealant, mortar squeezed out of the joint, and spalls along the bottom course above the angle are all signs the joint stopped doing its job — or that something behind it is taking up its space.

The fifth is water evidence inside. Stains on interior finishes at floor lines, damp insulation found during other work, and recurring leaks that do not match any visible opening on the outside often trace back to shelf angle flashing that has failed, been omitted, or been punctured. The flashing over a shelf angle is supposed to collect water in the wall and direct it out through weeps. When it fails, water sits on the steel. That is the worst place for it to sit.

None of these clues, alone, is a diagnosis. Two or three together, at the same floor line, on the same elevation, is a strong case that the hidden steel needs direct attention.

Composite example: A property manager calls about recurring brick spalls on a two-story retail building — not scattered spalls, but spalls concentrated in one horizontal band. A walk-around finds rust staining at the same band, two weeps that are blocked with mortar, and a soft joint that a previous crew filled solid with mortar during a tuckpointing job. Each fact alone could be explained away. Together they describe a shelf angle that has been sitting in trapped water, behind a joint that can no longer move. The spalls are the veneer being pushed off its own face by pressure from behind.

How Water Gets to the Steel — and Why It Stays

If you remember one thing from this chapter, make it this: shelf angles rarely fail because the steel was too weak on the day it was installed. They fail because water management failed over years.

Water enters a veneer wall by design. Brick veneer is a rain screen, not a waterproof skin. Rain drives into the brick, mortar joints absorb moisture, and condensation forms in the cavity. A healthy wall handles all of that: flashing collects the water, the cavity drains, weeps let it out, and the steel stays mostly dry most of the time.

Failure starts when any link in that chain breaks. Flashing that stops short of the angle's ends lets water run off the side and onto the steel. End dams that were never formed let water spill into the wall at jambs. Weeps blocked by mortar, landscaping, or paving changes trap water at the lowest point — which is right on top of the angle. Mortar droppings in the cavity bridge moisture from the veneer straight to the backup and the steel. Sealant smeared over weeps during a repaint seals the drain shut.

Texas weather makes all of this worse in a particular way. Long hot spells bake a wall dry, then a hard driven rain soaks it in an hour. The steel cycles wet and dry, wet and dry, and that cycling — oxygen, moisture, oxygen again — is exactly what corrosion feeds on. A piece of steel that stayed permanently submerged might actually corrode more slowly than one that cycles. Our walls cycle constantly.

Once corrosion starts, it protects itself. Rust is porous. It holds moisture against the remaining sound steel, so the process continues even during dry weeks, in the damp pocket the rust itself maintains. Cleaning the surface and repainting the visible edge of an angle, without addressing the water and the hidden section, is cosmetic work. It may look better for a season. It does not change what is happening behind the brick.

This is also why age alone is a poor guide. A thirty-year-old building with good flashing, open weeps, and a dry cavity may have shelf angles in fine condition. A twelve-year-old building with blocked weeps and failed flashing may already have serious section loss. Diagnose the water history, not just the birthday.

When Opening the Wall Is Justified

Opening a veneer is disruptive and expensive, and no responsible contractor proposes it lightly. But there is a point where diagnosing from the surface stops being careful and starts being guessing, and guessing about structural steel is not a service to the owner.

Opening the wall is justified when displacement is measurable and progressing; when cracks at a floor line are widening season to season; when rust staining is heavy and paired with spalling or lifting; when interior water damage lines up with the angle location; or when a planned repair — repointing, sealant replacement, veneer work — would bury the evidence for another twenty years if the steel is not checked first. That last case matters more than people think. Fresh sealant and new mortar over a failing angle do not just waste money. They close the wall's relief points and trap more water, and they make the eventual repair bigger.

A proper exploratory opening is small, planned, and documented. Choose the location where clues are strongest, and usually a second location where they are weakest, so you have a comparison. Remove brick carefully over a short length of angle — enough to see the steel, the flashing, the anchorage, and the cavity condition. Photograph everything before touching it. Measure remaining steel thickness. Note whether flashing exists, what it is made of, and where it ends. Check the weeps and the soft joint from the inside of the work, where the truth is visible.

What you find decides the scope. Surface corrosion with sound thickness and intact flashing may need cleaning, a proper protective coating, flashing repair, and restored drainage — with the wall closed back up using matching units and mortar. Advanced section loss, failed anchorage, or a deformed angle is a different conversation: temporary support of the veneer section above, removal and replacement of the angle in sequenced lengths, new flashing with end dams, new weeps, and a functioning soft joint. Work of that scale, on a multi-story building, is work to plan with a licensed structural engineer engaged by the owner. Fifty years of hands-on field experience tells you what you are looking at and how the repair should be sequenced; it does not replace the engineer's role in evaluating the structure as a whole, and a straight answer to the owner includes saying so.

For the field-developed LintelLOCK system, the lesson of this chapter applies in reverse: any repair system installed at an opening or a shelf line has to respect drainage, flashing, and movement, or it becomes part of the water problem. Steel placed in a wall must be protected, the water must have a way out, and the joints must be allowed to move. A repair that ignores those three things is a future exploratory opening waiting to happen.

Close every opening the way you would want it closed on your own building: sound steel protected, flashing continuous with end dams, cavity clean, weeps open and verifiable, soft joint truly soft, and brick relaid to match. Then write down what you found and what you did, floor by floor and elevation by elevation. On complex buildings, that record is worth almost as much as the repair, because the next set of eyes — ten or twenty years from now — will start from your notes instead of from a crack and a guess.

Chapter 5: Wide, Tall, and Heavy — Long Spans and Concentrated Loads

A standard window opening in a brick house is a forgiving

problem. The span is short, the load above is modest, and the masonry itself helps by arching over the opening and shedding load to either side. Stretch that opening to sixteen, twenty, or twenty-four feet — a three-car garage, a storefront, a wide covered patio — stack two or three stories of masonry and roof load above it, and land a beam or a row of joists right over the middle of it, and the problem changes completely. Not just in size. In kind.

Long spans fail differently from short spans. They deflect more, they crack in different places, they punish small errors in bearing and leveling, and they give you less warning in some ways and more in others. This chapter works through how to think about wide, tall, and heavy openings at an advanced level: where the load actually comes from, what a concentrated load does that a uniform load does not, and why deflection — not raw strength — is so often the limit that decides whether a repair holds.

Tributary Load: Counting What Is Really Above the Opening

Every lintel carries a tributary area — the portion of the wall and structure whose weight and loads resolve down through that opening. For a short opening in a single-story wall, the classic picture is a triangle of masonry above the lintel, with the masonry outside that triangle arching to the sides. For tall, heavy, multi-story construction, that comfortable picture breaks down, and relying on it undercounts the load badly.

When there are floor lines, shelf angles, roof structures, and stacked openings above, load paths layer on top of each other. A second-story floor may bear on the wall directly above your opening. A roof truss may land every few feet along the wall. Another opening above may push its own jamb loads down into the same piers your lintel bears on. If shelf angles relieve the veneer at each floor, the veneer load on your lintel may be limited to one story — but the backup wall and the structure behind it may still be delivering far more.

The field habit to build is simple: before you size or judge any wide lintel, walk the load down, story by story, on paper. Start at the roof. What bears on this wall — trusses, rafters, a ridge, a parapet? Then each floor. Do joists run parallel to the wall or bear into it? Is there a beam, and where does that beam land? Then the wall itself. How many wythes, how tall is each stack between relief points, and are there openings above that concentrate load onto narrow sections of wall? Finally, live and environmental loads that the structure was designed around — occupancy, storage, wind on a tall elevation — which are the engineer's territory to quantify, but yours to remember exist.

Hypothetical example: A two-story commercial building has a twenty-foot storefront opening. Above it is a full story of brick veneer, a parapet, and a roof structure whose bar joists bear on the wall above the storefront every five feet. A quick look says the lintel carries one story of brick. A careful walk-down says it also receives point reactions from four joists, delivered through the wall, at five-foot intervals — and the two end reactions land close to the lintel's bearings, while the middle two land near mid-span, where they do the most harm. Same opening, same wall, two completely different load pictures. The second picture is the one that explains the cracks.

On work of this scale, your field assessment and the structural engineer's evaluation belong together. Your job is to report exactly what is built — spans, bearings, materials, observed movement, what bears where — and to recognize when the load picture is beyond rule-of-thumb sizing. Their job is the calculation. A repair planned from an undercounted load will be an underbuilt repair no matter how clean the masonry work is.

Concentrated Loads and Why Mid-Span Is Unforgiving

A uniform load spreads its demand evenly. A concentrated load — a point load — focuses it. A steel beam framing in from behind, a girder truss landing over the opening, a column post standing on the wall above, or a safe, a stone-clad feature, or mechanical equipment bearing on a floor above can each deliver, at one point, what a whole section of wall would deliver spread out.

Where the point lands matters as much as how big it is. A point load near a bearing mostly adds shear and bearing pressure at the support. A point load at mid-span adds maximum bending demand at exactly the place the lintel is already working hardest under uniform load. Two point loads at the third points can be worse still. This is why two openings with identical spans and identical walls can behave completely differently: one carries its structure spread out, the other has a beam landing dead center.

Concentrated loads also travel through masonry in ways that surprise people. Masonry spreads a point load as it moves down through the wall, roughly in a widening cone, but openings, joints, and shelf angles interrupt that spread. A beam bearing on the wall two feet to the side of your opening may still deliver a large share of its reaction onto your lintel's bearing pier — the narrow stack of masonry between two openings, for example — overloading the pier even though the lintel itself is adequate. Pier crushing, vertical splitting cracks in narrow piers, and mortar joint squeeze-out between

openings are pier problems, not lintel problems, and replacing the lintel will not fix them.

Composite example: A wide garage opening in a two-story home shows a sagging lintel and diagonal cracks from both upper corners — a familiar picture. Less familiar is the vertical crack in the narrow pier between the garage opening and a side entry door, and the fact that the replacement lintel installed three years earlier sagged in exactly the same way. A walk-down finds the second-floor girder truss bearing almost directly over that pier. The lintel was never the root problem. The pier was being asked to carry a concentrated truss reaction plus both openings' jamb loads, and the lintel kept being blamed because it was the piece that visibly bent. Fixing the load path at the pier — and addressing the truss bearing with the owner's structural engineer — is what finally breaks the cycle.

Field rule: on any wide opening, find every beam pocket, joist hanger, truss bearing, and post above the opening before you propose anything. Sketch them to scale along the span. The sketch, more than any single measurement, is what separates a diagnosis from a guess.

Deflection: The Limit You Can See

Here is the hard truth about long lintels: they usually become unacceptable because they bend too much long before they are in danger of breaking. Strength and stiffness are different properties. A steel member can be strong enough not to fail and still deflect enough to crack the masonry above it, rack the units at its bearings, open joints to water, and make doors and storefront systems below it bind and leak.

Masonry is stiff and brittle. It tolerates very little curvature. As a long lintel deflects under load, the brick above tries to follow the curve; mortar joints open on the underside of the arching zone, step cracks run from the points of greatest slope, and the bearing ends rotate slightly, concentrating pressure on the inside edges of the bearing. The longer the span, the more total deflection the same proportional bend produces — double the span and, all else equal, deflection grows far faster than the span does. That mathematical fact is why experience from six-foot openings does not transfer to twenty-foot openings. The loads grow, but the bending grows faster.

This is why deflection limits — commonly expressed as a fraction of the span, such as span divided by a set number — exist in design practice, and why they are stricter for members supporting masonry than for members supporting flexible finishes. The exact limit for a given project is a design decision for the engineer of record. The field takeaway is

simpler: when you evaluate a long-span repair, ask not only "will it hold?" but "how much will it move under load, and can the masonry above it live with that movement?" A repair that answers only the first question will crack politely and repeatedly while never technically failing.

Deflection also explains a pattern many masons have seen and misread: cracks that appear weeks after a wide lintel is installed, on a job that looked perfect at completion. The lintel went in unloaded or lightly loaded. Then the masonry above was built or re-laid, the structure above was reconnected, finishes and storefront framing went in — and as full load came onto the span, it took its working deflection all at once, and the new masonry, cured hard and unable to adjust, cracked. Proper practice anticipates this: adequate stiffness, proper camber where the design calls for it, correct shoring and load sequencing during the repair, and mortar and joint details that do not lock the veneer rigidly to a member that is going to move.

In the field-developed LintelLOCK system, long-span work is approached with that same respect for movement: support and sequencing during the repair matter as much as the final assembly, bearings must be full, level, and verified, and any span where calculated deflection governs is a span to walk through with the owner's structural engineer before work begins — not after cracks provide the lesson.

Why Long Spans Fail Differently — and How to Repair Them in Sequence

Put the pieces together and the failure signatures of long spans make sense. Short lintels tend to fail at the steel itself: corrosion, section loss, a bearing that gave way. Long lintels tend to fail as systems. The member deflects, the masonry cracks in a broad pattern rather than at one point, bearings rotate and spall, the backup structure's own deflection adds to the lintel's, and thermal and moisture movement over a long continuous length — a twenty-foot steel member changes length measurably between a cold morning and a hot afternoon — works joints and connections season after season. Water enters through the movement-opened joints, corrosion begins at the bearings and the underside, and only then does the steel itself start to go. By the time a long span looks bad, several causes are usually stacked on top of each other.

Repair sequencing, therefore, is the heart of long-span work. The veneer and structure above must be properly shored and the load path controlled before the existing member comes out — not held up by optimism and a couple of props placed where they fit. The span should come out and go back in

planned sections where the design requires it. Bearings should be rebuilt to full, level bearing with sound masonry, not packed out with shims and hope. The new work should be loaded in a controlled order, shores released gradually, and joints — especially the soft joints at shelf lines and the movement joints at the ends of long members — restored to working condition, not filled solid in the enthusiasm of finishing day.

Hypothetical example: A contractor is asked to "just replace the rusted lintel" over an eighteen-foot patio opening with a stone-clad wall above. His inspection finds the lintel rusted, yes — but also a point load from a roof beam landing near mid-span, a bearing pier with a splitting crack, and a soft joint packed with mortar. He presents the owner with the whole picture and a sequenced plan that addresses all four items, with an engineer engaged for the beam and pier evaluation. It is a bigger conversation than the owner expected. It is also the difference between a repair and a repeat.

Wide, tall, and heavy openings reward the contractor who slows down at the start. Count the load. Find the points. Respect the bend. Sequence the work. Do those four things, and long spans stop being the jobs that come back — and become the jobs your reputation is built on.

Chapter 6: Historic Lintels — Stone, Cast Iron, and Early Steel

Working over an opening in a building that has stood for a hundred years is a different kind of responsibility. The materials are different — stone that was cut by hand, cast iron poured in a foundry that no longer exists, early steel rolled to shapes no catalog lists anymore. The mortar is different. The rules the original builders followed were learned from craft tradition rather than code books. And the building itself has a value beyond its function: it is a record. A careless repair can erase in a day what a century preserved.

None of that means historic lintels cannot be repaired, strengthened, or — when they are truly finished — replaced. It means the work starts with reading before it starts with tools, proceeds more gently than modern work, and respects materials that behave in ways modern materials do not. This chapter covers how to read historic openings, how stone, cast iron, and early steel each fail, and how to match profiles and mortars so a repair serves the building instead of fighting it.

Reading a Historic Opening Before You Touch It

A historic opening tells its story in its proportions. Older masons sized lintels by rules of thumb refined over generations: the depth of a stone lintel related to its span, the bearing length related to the load and the softness of the supporting masonry, the rise of a flat arch related to the opening's width. When you find an opening that has performed for a century, those proportions are data. Measure them. Record the span, the lintel depth and thickness, the bearing at each end, the joint pattern in the masonry above, and whether the load above is carried by the lintel alone or helped by a relieving arch hidden in the wall — many historic walls conceal a brick arch above a stone or timber-faced lintel, quietly doing most of the work.

Look at how the opening has moved. Historic buildings have usually finished their settlement long ago, so cracks in and around a historic lintel are more likely to speak of material failure — a stone that has cracked through, iron that has corroded and jacked, a bearing that has crushed — than of a foundation still on the move. Note whether cracks are old and stable, with dirt and weathering deep in them, or fresh and sharp. Old, stable cracking may need monitoring and pointing; active material failure needs intervention. The distinction decides the scope, and getting it wrong in either direction wastes either money or history.

Document before you disturb. Photographs from square-on and from angles, close views of profiles and tooling marks, and notes on any markings — foundry names, quarry marks, carpenter's or mason's marks — all belong in the job record. On designated historic properties, there may also be formal constraints: preservation guidelines that govern what can be altered, requirements that original material be retained and repaired rather than replaced, and review processes that must approve the approach before work starts. Learn those constraints at the beginning, from the owner and the governing body, not from a stop-work conversation in the middle.

Hypothetical example: A downtown building from the 1910s has a cracked stone lintel over its main entry. The crack runs vertically near mid-span, the classic signature of a stone lintel loaded in bending beyond what stone can take in tension. Before proposing anything, the contractor measures the wall and finds, by probing a mortar joint above, that there is no relieving arch — the stone has been carrying the full triangle of masonry above it for a century, helped only by the masonry's own arching action, which a later storefront alteration partially cut away. The crack, in other words, is not the stone's fault. An alteration changed its job. The correct repair conversation starts with restoring a load path, not with blaming or simply swapping the stone.

Stone, Cast Iron, and Early Steel: Three Materials, Three Behaviors

Stone lintels are strong in compression and weak in tension, and a lintel is a bending member — its bottom face is in tension. That single fact explains most stone lintel failures. A stone lintel survives by being deep for its span, by carrying limited load, and often by the quiet help of arching action in the wall. Cracks typically appear at or near mid-span on the underside and run upward; a through-crack at mid-span means the lintel is now effectively two stones bearing against each other, stable perhaps under light load, but with no reserve. Stone also fails at bearings, where concentrated pressure can spall the ends, and along natural bedding planes — sedimentary stone laid with its bed horizontal, as it should be, behaves very differently from a piece set on edge, which can delaminate under load and weather. Repairs to stone favor restraint: stitching and pinning sound stone, supporting it with a discreet secondary member concealed above or behind, or relieving it of load so it remains in place as a facing rather than a structure. Replacing a stone lintel in kind demands matching stone type, dimensions, finish, and tooling — and a frank conversation about cost and lead time.

Cast iron, common in storefronts and lintels from the mid-1800s into the early 1900s, is a different animal. It is strong in compression, brittle in tension and under impact, and it does not bend gracefully before it breaks — it fractures. Cast iron lintels and columns often carry foundry marks and decorative profiles that are part of a building's character. Their great enemy is corrosion at bearings and at water traps in their profiles, and the jacking force of that corrosion against surrounding masonry. A cast iron member that has cracked should never be welded casually or loaded with confidence after a surface repair; cast iron welding is a specialist skill, and evaluation of a cracked historic casting is work to do with a structural engineer experienced in historic structures. Often the sound approach is to relieve the casting of its structural duty — carrying the load on a new, concealed support — while retaining and repairing the casting itself as the visible historic fabric.

Early steel, from the 1890s through the 1920s, came in shapes that predate modern standardization: shallow beams, channels, and angles with dimensions and properties that do not match a modern table by name. Do not assume a six-inch historic beam equals a modern six-inch beam in capacity. Early steel quality also varied more than modern product. Sound early steel, protected from water, can still be doing its job perfectly well after a century; the usual failure is again corrosion, especially where the steel is embedded in masonry at bearings, and especially at parapets and cornices where water management failed. Where evaluation is needed, actual

measurement of the remaining section — not the nominal historic size — is what matters, and the engineer evaluating it needs those field measurements from you.

Composite example: A row building has three lintel types on one facade: stone over the windows, a cast iron storefront beam at street level, and early steel angles at a later rear addition. Each gets a different plan. The stone lintels, cracked but stable and relieved by sound relieving arches, are pinned, pointed with compatible mortar, and monitored. The cast iron storefront beam, corroded at one bearing, is relieved of load by a concealed new support while the casting is repaired by a specialist and retained. The early steel at the rear, measured in place, has enough sound section to stay, with cleaning, protection, and flashing repair. One building, three materials, three answers — because the materials, not habit, set the plan.

Mortar Compatibility and Working Gently

If there is one technical mistake that damages more historic masonry than any other, it is repointing or repairing with a mortar that is too hard. Historic brick and stone were typically laid in lime-rich mortars that are softer than the masonry units, weaker in compression, more vapor-permeable, and able to accommodate small movements. That softness is a feature: the mortar is the sacrificial element, meant to weather slowly and be renewed, and to let moisture escape through the joints rather than through the faces of the units.

A hard, modern, cement-rich mortar reverses that relationship. Moisture that should exit through the joint is driven through the brick or stone, carrying salts that crystallize and spall the faces. Movement that the soft joint would have absorbed cracks the units instead. Within a decade or two, a hard repointing job can do more damage to a historic wall than the previous century did. The field rule is absolute: repair mortar must be no harder than the original, matched in composition as closely as practical, and matched in color, texture, tooling, and joint profile, so the repair reads as part of the wall. Where the original mortar's composition is in question on a significant building, laboratory analysis of a sample is money well spent, and preservation guidance for the property should be followed.

Working gently is the companion discipline. Historic material comes apart differently — lime mortar releases with patience and hand tools where a grinder would scar every arris it touched. Units that are to be saved and relaid need to be removed whole, cleaned by hand, and kept in order. Aggressive demolition, hard chiseling at bearings, and expanding anchors driven into old masonry without thought

can each destroy the very fabric the job exists to preserve. Shoring and support during historic lintel work should be planned to avoid point loads against fragile material, and any new support member should be detailed so a future generation can understand what was done and, if needed, undo it. Reversibility, or at least retreatability, is a respected principle in preservation work: do not make your repair the next century's problem.

Matching historic profiles completes the picture. When a lintel, sill, or section of profiled material must be replaced, match the original dimensions, profile, and finish — not approximately, but faithfully, working from measured drawings and photographs of the original and, where possible, from a surviving twin elsewhere on the building. New stone should match the original in type and bedding orientation. Replacement metalwork should reproduce the visible profile even if its internal construction is modern and concealed. The goal is a repair that a knowledgeable eye, told where to look, can identify as honest new work — and that everyone else simply sees as the building, whole again.

Hypothetical example: A historic home has a spalling brick problem that appeared within eight years of a full repointing job. Examination finds the new mortar noticeably harder than the original lime mortar found in protected joints, and the spalls concentrated on the softest, oldest brick. The fix is not another harder coating or a sealer. It is the slow, honest work of removing the damaging mortar where feasible without further harm, repointing with a compatible lime-based mortar, and accepting that some face loss is permanent. The example is labeled hypothetical, but the mechanism is one every experienced mason working on old buildings in Texas has seen in some form: the wall was not worn out — it was repaired against its own nature.

Historic lintels ask for a particular combination: a mason's hands, a reader's patience, and the humility to bring in preservation and structural specialists where the building's significance or condition calls for them. Bring all three, and a hundred-year-old opening gets the one thing it most needs from us — a repair that lets it be there, working, a hundred years from now. Where a modern support approach is appropriate and approved for a historic opening, the field-developed LintelLOCK system can be considered among the options, detailed discreetly and reversibly, and judged by the same standard as every other intervention in this chapter: does it protect the original fabric, respect how the old materials behave, and leave the building's story intact? If the answer is yes, proceed gently. If it is not, choose the approach that answers yes — because on historic work, the building, not the method, is what matters most.

Chapter 7: Shoring That Holds — Temporary Support and Safe Sequencing

Every permanent lintel repair begins before a single brick comes out. It begins with the load. A wall above an opening is not decoration waiting to be held up by habit. It is weight, live and dead, following a path down through masonry, through the lintel, into the bearing at each end, and from there into the wall below and the ground. When you remove a failed lintel, you interrupt that path. Shoring is how you give the load a new, temporary path that is just as deliberate as the permanent one will be. Done well, shoring is quiet work. Nothing moves, nothing cracks, no one on the crew has to react to a surprise. Done poorly, shoring is the moment a repairable opening becomes a partial collapse, an injury, or a building that will never sit quite right again.

After 50 years of hands-on field experience in Texas, I can tell you the pattern plainly: most shoring failures are not failures of steel or timber. They are failures of sequence, of bearing, and of patience. The crew knew how to prop a wall in general, but they did not study this wall, on this building, with this occupancy, in this weather. This chapter is about studying the specific case and building temporary support that holds from the first cut to the final strike.

Needle Beams, Posts, and Where the Load Actually Goes

A needle beam is a short, strong beam passed through the wall above the opening so that the masonry above can rest on it while the lintel below is removed. The needle itself is only half the system. Each end of the needle must land on a post, a crib, or a framed support, and that support must land on ground or structure that can carry the load without sinking, punching through, or shifting sideways.

Start by reading the wall. How thick is it? Is it a single wythe of brick veneer over frame, solid multi-wythe masonry, stone, or brick over concrete block? How wide is the opening, and how much masonry sits above it before a floor, a roof, or another opening interrupts the load? In solid masonry, load tends to spread upward and outward at an angle from the opening. That spreading helps, but you never count on it as your support. You shore as if the full section above the opening needs you, because cracked or previously repaired masonry may not arch the way sound masonry does.

Choose needles for stiffness as well as strength. A support that flexes under load will let the wall settle a fraction, and a

fraction is enough to crack plaster inside or bind a window frame. Steel section, heavy timber in sound condition, or purpose-built needle sections all have a place, provided they are sized for the span and weight, bear fully, and do not roll or twist. Place needles close enough that the masonry between them is not asked to span farther than it safely can. On long or heavily loaded openings, that means more needles, not stronger wishes.

Posts follow the same rule. Adjustable steel shoring posts are useful because they allow controlled, even lifting and leveling, but only when they are plumb, fully seated, pinned or locked as designed, and set on sole boards or pads that spread the load. A post standing on a single brick, a scrap of plywood on soft soil, or the edge of a slab is not a support system. It is a point waiting to fail. Where posts land on soil, spread the load over a broad, level pad and check it after the first transfer and again after any rain. Where posts land on a floor or deck inside a building, confirm what is under that floor. A post that carries a wall down onto a weak floor simply moves the problem one level down.

Load transfer is a controlled event, not a lift. Bring the shoring up snug and even, a little at a time across all posts, watching the wall, the needles, and the existing cracks as you go. Tell-tale markers across existing cracks — a dated pencil line, a small plaster tell, or a measured gap recorded in a notebook — will tell you if anything moves. The goal is to take the weight without jacking the wall up. Lifting a wall even slightly can crack finishes far from the opening, because when you later lower the load onto the new lintel, the wall settles back and opens the very joints you just built. Take the load, do not raise the building.

Sequencing Multi-Opening Work Without Losing the Building

One opening at a time is the safest sequence, and on complex buildings it should be the default. When a facade has several failed lintels — a row of windows on a school, a line of storefronts, paired openings in a historic home — the temptation is to open everything at once to save trips and scaffolding. Resist it unless a careful plan, prepared for that specific structure, shows the wall can tolerate it and the shoring for each opening is fully independent. Every opening you cut removes bearing and interrupts the wall's ability to help its neighbor. Two adjacent openings shored at the same time can leave the pier between them carrying far more than it ever carried before, on a reduced section, at the exact moment you are working under it.

Sequence by risk. Start with the opening that teaches you the

most about the building — wall thickness, hidden steel condition, flashing condition, bearing condition — with the least consequence if surprises appear. Use what you learn to adjust the plan for the harder openings. Work from a stable section toward a weaker section, never the reverse, so that your completed, cured work becomes part of the support for what follows rather than a fresh repair being loaded by the next cut.

Within a single wide opening, sequence matters just as much. Shore first, prove the shoring by observation, then remove masonry in small, controlled sections, keeping the exposed area no larger than you can rebuild or secure the same day. Remove the failed lintel only after its load is fully on the needles. If the lintel is built into the wall in sections, or if corrosion has expanded it and locked it into the surrounding masonry, cut it out in pieces rather than prying against masonry you intend to keep. Prying feels fast. It also splits bearing bricks, loosens courses above the needles, and destroys the evidence you need to understand why the lintel failed.

Keep a written sequence on site, in order, and brief every person on the crew on it before work starts. If conditions inside the wall do not match the plan — a hidden flue, voids, a rotted backup wall — work stops at a safe, shored state and the plan is revised before removal continues. Where loads, spans, or conditions are beyond straightforward field judgment, advise the owner to hire a structural engineer to review the shoring and sequencing plan before work begins. That protects the owner, the building, and the crew.

Composite example: A two-story building has five window lintels failing on the same elevation, with a narrow brick pier between the third and fourth windows already cracked. A sequenced approach shores and completes the first, second, and fifth openings one at a time, learns that the hidden flashing is missing throughout, then treats the third and fourth openings and the cracked pier between them as a single problem with its own shoring plan. The job takes longer on the calendar and far less time in total, because nothing has to be redone and the pier is never left overloaded.

Weather, Occupancy, and the Building in Use

Shoring does not happen in a laboratory. It happens on buildings where people live, work, learn, and walk past, often in Texas weather that can change the ground, the wind load on a scaffold, and the safety of a roof edge in a single afternoon. Plan for the building in use, not the building you wish you had empty.

Occupancy comes first. No one works, sleeps, or gathers under a shored opening unless the support system and the work plan were designed for that condition and the area has been reviewed that day. In most field repairs, the honest answer is simpler: clear the zone below and on both sides of the work, close the doorway or window from use, and route people around. Barriers need to be physical, not just tape, where a falling brick is possible. Inside, protect floors and finishes, shut down systems that vibrate the wall, and tell occupants plainly what noise, dust, and closures to expect and for how long. A surprised occupant who opens a window into your work zone is a safety problem you created by not communicating.

Weather changes the calculation in specific ways. Rain softens soil under posts, adds weight to saturated masonry, and can flood an open wall cavity if temporary covers are not in place. Never leave an opened wall overnight without a weather plan: covering that sheds water away from the cavity, secured against wind, and a check after any storm before work resumes. Wind matters for sheet materials and tall, braced posts. Extreme heat affects the crew as well as materials; a tired, dehydrated crew makes sequencing mistakes, so build rest, water, and shade into the day. Watch the forecast before you open, not after. Lightning ends elevated and steel-heavy work until it has passed at a safe distance. That rule has no schedule exception.

Hypothetical example: A shored garage opening is left for the weekend with the covering tucked into the cavity rather than lapped to shed water outward. Heavy rain saturates the backup wall and adds damage the original repair never included. Temporary weatherproofing is real work. Give it real time.

Safety Rules That Are Never Bent

Some rules flex with conditions. These do not.

Never work under an unsupported load. If the shoring is not in, proven, and watched, hands and heads stay out from under the masonry. Never remove a post, a needle, or a brace because it is in the way of the next task. If it is in the way, the sequence is wrong — stop and re-sequence, with additional support installed and loaded before the obstructing support is touched. Never use damaged posts, bent needles, cracked timbers, or makeshift extensions. A support with a visible defect has already told you its answer. Never stack loose material under a post to gain height. Use the post's proper adjustment range or a properly built crib, level and fully bearing. Never allow vehicle traffic, material stockpiles, or a loaded scaffold to add unplanned weight near post pads without reviewing what that weight does to the ground or

floor below.

Check the system at set moments, not just when something looks wrong: after initial load transfer, at the start of each workday, after any impact, storm, or nearby excavation, after any adjustment, and before any person works in the zone. Record the checks in a dated line in the site notebook — who checked, what was checked, what was found.

Finally, one person owns the shoring on each shift. A single named lead decides when load is transferred, when removal may begin, and when shoring may be struck. Divided authority is how a post gets loosened by one crew member while another is removing steel beneath it. Clear ownership, a written sequence, and the discipline to stop when the wall tells a different story than the plan — that is shoring that holds.

Chapter 8: The Permanent Replacement — LintelLOCK on Complex Openings

A temporary support that holds earns you the right to do the permanent work carefully. This chapter walks the permanent replacement step by step on the openings that punish shortcuts: wide spans, grouped windows, arched and historic masonry, storefronts with heavy load above, and openings where the bearing, the backup wall, or the original construction is not what the surface suggested. The method described here is the field-developed LintelLOCK system — his field-developed system, built out of 50 years of hands-on field experience in Texas and refined opening by opening — applied with the patience complex work requires. It is not a product you drop into a hole. It is a sequence, and every step either prepares the next one or undermines it.

A note on limits before the sequence begins. Complex openings sometimes reveal conditions that call for design input beyond field experience: unusually long spans, concentrated loads from beams or columns landing near the opening, cracked piers, or a building whose structure has already moved. In those cases, advise the owner to hire a structural engineer to review the condition and the proposed repair before permanent work proceeds. The steps below describe sound field practice for the mason. They do not replace that review where it is needed.

Survey, Shore, and Remove Without Destroying Evidence

The survey is not a glance and a measurement for ordering steel. Record the opening width, the height and weight of masonry above, the existing lintel type and section, the bearing length at each end and the condition of the bearing masonry, the state of the mortar and units for several courses above and beside the opening, the condition of any flashing and weep holes, the backup wall, and the interior finishes that movement would damage. Photograph everything before you touch it, including cracks with a ruler for scale and a dated marker across any crack you want to monitor. Measure the opening at several points; older openings are rarely square, and steel ordered to a single optimistic measurement arrives wrong.

Note how the failure presents. A sagging center, stepped cracks rising from the corners, rust staining, displaced units, and a lintel flange curled by corrosion each tell a different story about load, water, and time. That story decides details later — bearing repair, flashing design, corrosion protection — so preserve it in notes before demolition erases it.

Shoring follows Chapter 7 in full: needles and posts on sound bearing, load transferred evenly without lifting the wall, checks recorded, the zone cleared. On complex openings, add one discipline: prove the shoring under a pause. Transfer the load, wait, recheck your tell-tales and post pads, and only then begin removal. A system that will move usually announces it early, while you are still watching instead of cutting.

Removal is surgical. Take down masonry above the lintel only as far as the repair requires — enough to free the lintel, reach sound flashing planes, and rebuild properly, and no farther. Support or carefully set aside units you intend to reuse, especially on historic work where matching brick or stone may be irreplaceable. Cut mortar joints rather than smashing units. Remove the failed steel in sections if corrosion has swollen it tight against surrounding masonry; forcing a swollen section out in one piece can split the bearing and the pier. As each layer comes out, inspect what it reveals: the top of the backup wall, hidden conduit or piping, voids where mortar never reached, a second, earlier lintel buried in the wall. Log surprises and adjust the plan before proceeding. The wall you planned for and the wall you have are now the same document — read the real one.

Hypothetical example: On a wide opening in an older commercial building, removal reveals that one end of the failed lintel bears not on solid masonry but on a shallow stack of loose brick over a void, apparently an undocumented change from decades earlier. A crew in a hurry sets new steel on the same stack because the schedule says set steel today. A careful crew stops at a safe shored state, rebuilds the

bearing properly as described below, and sets steel a day later on support that will outlast the building's next fifty years. The day is not lost. The failure is prevented.

Prepare the Bearing, Set the Steel, and Protect It

No lintel is better than its bearing. The load that the new steel collects across the opening leaves the steel at its two ends, concentrated on the bearing areas. If those areas are cracked, soft, hollow, or too short, the new system begins its life by damaging the wall that holds it.

Prepare each bearing by removing damaged units and mortar down to sound material, rebuilding with sound units fully bedded, and providing a level, full-contact bearing surface at the correct elevation on both ends — matched, so the steel sits level without shimming stacks or point contacts. Bearing length matters: the steel must extend far enough onto sound masonry at each end to spread the concentrated end load without crushing or splitting the bearing. Wider spans, heavier load above, and weaker masonry all argue for more bearing, not less, and for spreading plates or pads where field conditions call for them. Where doubt exists about span, load, or bearing adequacy on a complex opening, that is the moment to advise the owner to bring in a structural engineer for review — before steel is set, while the question is still cheap to answer.

Set the new steel of the field-developed LintelLOCK system according to the surveyed dimensions and the specific opening: correct section for the span and load, oriented as intended, seated fully on both bearings, level, at the elevation that lets the masonry above rebuild to its proper courses without forced joints or cut units that weaken the face. Check the set before any masonry goes back: full bearing contact at both ends, no rocking, no twist, clearance and cover where the design of the repair requires it, and the flashing components — covered fully in the next chapter — positioned as part of the set, not remembered afterward. On wide openings, check for camber and deflection expectations honestly; steel that deflects noticeably under the rebuilt load will crack the new work just as the failed lintel did, only more slowly and at your name instead of time's.

Corrosion protection is not an afterthought coat of whatever is on the truck. Steel above an opening lives in a wall that will get wet again despite everyone's best flashing work, because walls are exterior systems in weather. Clean, properly coated steel, with coating repaired where handling or setting damaged it, and with attention to the bearing ends and any cut edges, is what separates a repair measured in decades

from one measured in years. Keep dissimilar materials from creating avoidable corrosion problems, keep the steel from sitting in trapped water by detailing the flashing and drainage as the next chapter describes, and never bury bare, unprotected steel in new masonry and call the burial protection. Mortar is not a coating. It holds moisture against steel as readily as it sheds it.

Composite example: Two neighboring wide openings receive new steel in the same week. On the first, bearings are rebuilt, steel is fully seated and coated, and flashing is integrated at the set. On the second, the steel is set on the old cracked bearing to save half a day and the coating damaged during setting is left untouched. Five years later the first opening is unremarkable, which is the goal. The second shows fresh staining at one end, because the bearing settled, the steel twisted slightly, and water found the unprotected spot. Permanent work is permanent only when the invisible steps are done.

Rebuild the Masonry, Cure, and Strike in Order

Rebuilding is where the repair either becomes part of the wall or remains a patch sitting in it. Lay units to the original bond and coursing unless the original pattern itself contributed to the failure and the plan, reviewed where needed, changes it deliberately. Bed joints full, head joints full, no furrowed beds that leave voids over the steel. Tool joints to match the surrounding work and to shed water. Keep the cavity, backup, and any insulation or backing in their intended condition as you rise — debris dropped behind the new work becomes a moisture bridge and a future diagnosis you will not enjoy making.

Build in lifts that respect the new steel and the fresh mortar. Loading green masonry hard and fast by rebuilding the full height in a rush, stockpiling units on the new work, or removing shoring to free posts for another job are all ways to make fresh work carry weight before it can. Mortar gains strength over time, not over enthusiasm. Follow the mortar maker's guidance and sound field practice for curing conditions: protect fresh work from driving rain that washes joints, from rapid drying in hot wind that starves the cure, and from freezing where it occurs. In Texas summer heat, that often means shading, light moisture care as appropriate for the materials in use, and scheduling the heaviest work away from the worst of the afternoon — for the mortar's sake as well as the crew's.

Weep holes and flashing terminations are finished as part of the rebuild, verified open and correctly placed before

scaffolding comes down, not drilled as an apology later. Chapter 9 covers the water system in detail; here, the rebuild rule is simple: if the rebuild buries, blocks, or reverses any part of the drainage path, the rebuild is wrong no matter how clean the face looks.

Striking the shoring is the mirror of setting it: deliberate, even, and in order. Confirm first that the rebuilt masonry and bearings have cured sufficiently for the load they are about to receive, that flashing and weeps are complete, and that nothing in the new work depends on a post staying one more day. Then ease the load from the posts onto the new lintel gradually and evenly across the opening, a little at a time, watching tell-tales, joints, and the steel line as the wall comes to rest on its permanent support. Remove posts and needles in the reverse logic of their installation, filling and repairing needle holes fully as you go so they do not become water paths. If any movement, cracking, or sound from the wall concerns you during the strike, stop, re-support, and reassess. A strike can be paused. A collapse cannot be unpaused.

After the strike, inspect again at a short interval — days later, and ideally after the first good rain — for new cracking, joint opening, staining, or ponding at the bearing ends. Record the final state with photographs matched to your survey photographs. The owner receives a clear summary: what was found, what was replaced, how the bearing and flashing were handled, and what to watch in the coming seasons. That record, kept honestly, is the difference between a repair that can be trusted and maintained and one that must be guessed at by the next mason — who, on a complex building, may be you, ten years older and grateful for your own notes.

Chapter 9: Water Above the Opening — Flashing Systems That End the Cycle

Ask a failed lintel why it failed and, nine times in ten, the honest answer is water. Steel does not rust in dry walls. Mortar does not soften and crumble in dry walls. The cycle that brings a mason back to the same opening every few years runs like this: water enters above the opening, reaches the lintel, corrosion begins, rust expands to many times the volume of the steel it came from, the expansion lifts and cracks the masonry above, the cracks admit more water, and the corrosion accelerates until the lintel can no longer carry its load. Replacing the steel without breaking the water cycle does not end that story. It restarts it with newer steel.

This chapter is about the system that ends the cycle: through-wall flashing, end dams, drip edges, and weep holes

working together as one drainage path, at the head of the opening and at shelf angles above it. After 50 years of hands-on field experience in Texas, I treat flashing not as an accessory to lintel work but as half the repair. The steel carries the load. The flashing keeps the steel alive.

Through-Wall Flashing, End Dams, and Drip Edges

Real flashing crosses the wall. That sentence decides most flashing questions before they are asked. A membrane, metal sheet, or combination system that extends from the backup wall through to the exterior face, lapped and sealed at its joints, collects water traveling down inside the wall and delivers it to the outside. Anything that stops short inside the wall — a partial flashing, a bead of sealant at the face, a coating on the exterior — may slow water for a season, but it does not collect and discharge the water that is already in the wall system, and in time that water finds the lintel below it anyway.

Install through-wall flashing above the lintel as a continuous pan for the opening. The back leg turns up against the backup wall high enough that wind-driven water running down the cavity cannot hop over it, and it is secured and sealed to the backup so water stays on the pan rather than behind it. Joints in the flashing are lapped in the direction of flow, sealed as the system requires, and kept to the fewest number the opening allows; every joint is a future inspection point, so place them thoughtfully and build them carefully. The pan slopes to the outside. Flashing installed level holds a thin sheet of water against the wall. Flashing installed sloping inward is worse than none at all, because it collects water from a wide area and delivers it efficiently to the interior.

End dams are the detail that separates a pan from a tray with open ends. At each end of the flashing, the material turns up and is sealed to form a dam, so collected water cannot run off the end of the flashing into the wall beside the opening — which is precisely where the lintel bearing sits. Water dumped at the bearing rots the bearing masonry, corrodes the lintel end where its load concentrates, and stains the interior corner in a way owners often misread as a roof leak. Form end dams at the correct height, seal their corners completely, and position them so the bearing stays dry while the pan still drains freely through its face. On wide openings, confirm the dam and the bearing rebuild from Chapter 8 agree with each other; details drawn or planned separately have a habit of occupying the same inch of wall.

The drip edge finishes the path. Where flashing exits the face of the wall, it should project slightly and turn down to form a

drip, so water leaving the pan breaks free and falls clear instead of curling back under the flashing by surface tension and re-entering the joint below. A flashing edge buried flush in a mortar joint, or worse, turned up at the face, will deliver its collected water straight back into the wall it was meant to protect. Keep the drip clear of sealant, mortar droppings, and paint bridges after installation. A drip painted shut by a later coating job is a failure scheduled by someone who never knew the detail existed, which is one more reason the owner's final summary from Chapter 8 should name the flashing and drip as features to preserve, not cover.

Hypothetical example: A long lintel is replaced with excellent steel, new through-wall flashing, and careful bearings — but no end dams, to save an hour. The first hard, wind-driven rain collects water on the pan, runs it to both ends, and discharges it into the wall at the bearings. Within two seasons, staining appears at both interior corners and the bearing mortar at one end is soft. The steel in the middle is fine. The repair is failing at its ends for want of two small upturned details. End dams are not trim. They are the ends of the system.

Weep Holes and the Difference Between Sealant and Flashing

Collected water needs an exit that is open on the day of the first rain, not an exit that exists in intention. Weep holes are those exits: openings at the base of the flashing pan, at the level where water collects, spaced regularly along the opening so no section of pan has to push water far to drain. Place weeps directly above the flashing, in the course the drainage plane serves, at a spacing close enough that a single blocked weep does not flood a long section — and then verify every weep is actually open before the scaffold drops. Mortar droppings are the great blocker of weeps. A wick, a rope section, or a formed weep device can help keep a drainage path through the joint, provided it is installed in the joint as the work rises rather than stuffed in afterward. Probe each weep gently, clear it, and record the check. A weep you did not test is a hope, not a hole.

Weep holes are never caulked shut to make a facade look tidy, and they are never the place a well-meaning painter seals because they look like gaps. Owners should be told, in plain language, what the weeps are and why they must stay open. Water that cannot leave at the weeps leaves somewhere else — through the interior face, through the bearing, or through a crack it creates by staying where it does not belong.

Now the distinction this chapter insists on: sealant joints and flashing are different tools doing different jobs, and confusing them is expensive. Sealant is a maintenance material with a

service life measured in years. It bridges a joint between materials, accommodates small movement, and sheds water at the surface for as long as its adhesion and flexibility last — and then it must be removed and renewed. Flashing is a drainage system built into the wall, intended to last the life of the repair, that manages water inside the wall whether the surface sealant is new or aged. A repair that substitutes a bead of sealant at the head of an opening for real flashing has an expiration date set by the sealant, and when it expires, water goes directly to the steel. Use sealant where it belongs: as the outer joint treatment where the design calls for it, tooled properly, over correct backing, never packed deep into the cavity as a substitute dam, and never bridging the weep path or the drip. Then tell the owner it is a maintenance item with a renewal interval, so its eventual aging is a planned task rather than a discovered leak.

Composite example: Two similar openings are repaired in the same year. The first receives through-wall flashing, end dams, a drip, and open weeps, with a modest sealant joint at the face. The second receives new steel and a generous, beautifully tooled sealant joint with no flashing behind it. For three years the second opening arguably looks better. In year four its sealant splits at one corner during a cold stretch, spring rains reach bare steel for a full season before anyone notices the hairline split, and the cycle from the start of this chapter begins again. The first opening's sealant also ages — and nothing happens, because behind it the flashing keeps collecting and discharging water as designed. That difference is the whole argument.

Head Flashing at Shelf Angles and Why New Steel Alone Fails Again

On larger and multi-story buildings, openings often sit below shelf angles — horizontal steel angles that carry masonry at a floor line and interrupt the wall's drainage. Everything said about lintels applies at a shelf angle with interest, because the angle collects water from the full height of wall above it, its horizontal leg forms a long trough, and its supports and attachments create penetrations where water concentrates. Head flashing at a shelf angle must collect water above the angle and discharge it through weeps below the course it serves, with end dams at terminations, columns, and changes of direction, and a drip that throws water clear of the face below. Where masonry below a shelf angle shows rust staining, displaced joints, or cracking that steps out from the angle line, read it as a flashing failure first and a masonry failure second. Rebuilding that masonry without rebuilding its flashing is scheduled repeat work.

Pay particular attention to continuity where systems meet.

Flashing above a lintel that discharges onto a shelf angle detail that discharges into an unflashed joint has not solved the wall; it has moved the wet spot down one floor. Walk the whole drainage path on paper or in person, from the top of the wall section to the final drip, and ask at every step: if a gallon of water arrives here, where does it go next, and what carries it? Every answer should name a material and a slope, not a hope and a sealant.

Which brings the book back to its central promise above the opening. A new lintel without flashing fails again for reasons that are not mysterious: water remains in the wall, water reaches unprotected or even well-protected steel in quantity and stays there, corrosion expands, masonry cracks, and water enters in greater quantity. The timetable varies with exposure — a windward elevation in driving rain runs the cycle faster than a sheltered one — but the direction never varies. Conversely, a sound lintel protected by a complete flashing system lives in a wall that manages its water: rain still enters the outer wythe, as it always will, but it is collected, dammed at the ends, dripped clear at the face, and wept out at the base before it can sit on steel and begin its slow work.

So finish every complex opening the same way you would want your own work finished. Survey the water path as carefully as the load path. Shore with discipline, set the field-developed LintelLOCK system on bearings built to receive it, protect the steel, rebuild the masonry fully, integrate the flashing as part of the set, verify every weep with your own hand, strike the shoring in order after a real cure, and inspect after the first rain. Then write it down for the owner.

Above the opening, nothing is hidden once you learn to look. The cracks map the load. The stains map the water. The flashing — present and complete, or absent and improvised — tells you whether the last repair was built to end the cycle or merely to restart it. Build the kind that ends it.

Chapter 10: Knowing the Line — When to Stop and Bring In a Structural Engineer

There is a line on every complex building where field experience stops being enough on its own. Knowing where that line sits is not weakness. It is the mark of a professional who intends to still be in business, and still be trusted, ten years from now.

I will state this plainly at the start of this chapter, because everything else in it depends on it: I am not a licensed engineer. I do not hold a Professional Engineer license, and I do not present myself as one. My authority in this trade comes from 50 years of hands-on field experience in brick, masonry, and foundation work across Texas — opening walls, reading cracks, removing failed lintels, and putting buildings back together so they stay together. That experience is real, and it is valuable. It is also not the same thing as a license to design structural systems or to stamp drawings. When a job crosses into design, calculation, and life-safety responsibility, that work belongs to a licensed structural engineer. My job is to recognize that moment early, bring the right engineer in, and give that engineer clean field information to work from.

This chapter is about that recognition. On a simple single-story garage opening with a rusted lintel and stable brick above it, an experienced mason knows the work cold. On a taller, older, altered, or actively moving building, the same confidence can become a liability if it is not paired with judgment. The lintel is never just a piece of steel. It is carrying a load path, and when that load path is uncertain, changed, or failing in more than one place, you stop and get help before you remove anything else.

Referral Thresholds Every Pro Should Memorize

Build yourself a short list of thresholds, and do not negotiate with it in the field when the pressure is on to keep moving.

Refer the job, or pause for an engineer review, when the opening is wide and the load above it is heavy or unclear. As spans grow, so do deflection, bearing demands, and the consequences of a small misjudgment. A narrow window lintel and a wide storefront or multi-car opening are not the same problem scaled up. They are different problems.

Refer when bearing is compromised. If the brick or masonry at either end of the lintel is crushed, hollow, spalled through, stepped out of plane, or bearing on material you cannot identify with confidence, you do not have a sound place to land a new lintel. Replacing steel without resolving bearing just moves the failure to the ends.

Refer when you find hidden or altered structure. Cut joists, added openings, removed piers, steel that was never sized for the addition above it, a second story added over a first story that was never built for it, signs of a prior fire, or framing that has been notched and patched more than once — all of these mean the load path you see is not the load path the building started with. You cannot forensically read a building that has

been changed in ways no one documented and then pretend the original logic still applies.

Refer when the foundation is part of the story. Lintel distress that lines up with foundation movement — doors racking on the same wall line, stair-step cracking that continues below the opening to the grade beam, separation at corners — points to a system problem. At Metro Foundation Repair, foundation work means pressed concrete piles only, and even that work has its own limits and evaluation process. A lintel replacement that ignores moving support underneath it will not hold, no matter how well the masonry above it is rebuilt.

Refer when the wall itself is a structural system you cannot fully assess from the surface. Thick multi-wythe walls with deteriorated inner wythes, unreinforced masonry on older commercial buildings, parapets with widespread through-wall cracking, and walls that sound hollow over large areas when tapped all deserve a second, licensed set of eyes before demolition begins.

A useful field rule: if you cannot explain, in plain language, exactly what is carrying what, all the way to the ground, you are not ready to remove the existing support. Stop, document, and refer.

Active Movement and Life-Safety Signs

Some signs do not call for a referral next week. They call for a stop today.

Active movement shows itself in fresh, sharp crack edges with no paint or dirt bridging them, cracks that have reopened after a prior repair, tell-tale monitors or tape markers that have torn, doors and windows that worked last season and now bind, and new sounds — popping, groaning, or grit falling inside a wall cavity. Seasonal movement in Texas clay soils is real, and experienced pros learn its rhythm. Active, accelerating, or one-directional movement is different. It means the building is still going somewhere, and removing a lintel in the middle of that travel removes one of the few things tying the opening together.

Life-safety signs raise the stakes further. Treat these as stop-and-secure conditions: a lintel deflected so far that brick units are sliding or the arching action above the opening has visibly broken down; loose units overhead where people walk, park, or gather; a parapet leaning out of plane over a sidewalk or entry; cracking that passes through multiple floors on the same line; separation between a wall and the floor or roof structure behind it; and any condition where a section of masonry could fall if the remaining support shifts during your work. On multi-story buildings, the fall energy

and the number of people exposed below change the decision entirely. What might be a manageable repair on a single-story ranch becomes a public-safety problem three stories above a busy entry.

In those conditions, the professional sequence is short. Stop demolition. Shore only if you are trained and equipped to shore safely and the shoring itself does not create a new hazard. Keep people clear of the fall zone. Document from a safe distance. Call the owner, explain what you found in plain language, and bring in a structural engineer, and where required, the local building official. Do not let a schedule, a tenant opening date, or an owner who wants a cheaper answer talk you past a sign your eyes already understood.

Hypothetical example: A two-story mixed-use building shows a deflected lintel over a ground-floor entry, fresh cracking running through the second-floor window above it on the same vertical line, and loose brick at the parapet. Treating that as three separate small repairs misses the point. As a single pattern, it is a referral on first sight, with the entry protected until the engineer has seen it.

How Pros Work With an Engineer — Not Around One

Good engineers do not slow good masons down. They make the hard jobs defensible, buildable, and safer for everyone on site.

Bring the engineer in early, before you have priced yourself into a corner or promised the owner a method. An early site walk costs far less than a redesign after demolition has exposed a condition no one planned for. Be specific about what you need: assessment of the load path, sizing or confirmation of the replacement support, bearing details, shoring requirements, sequencing limits, and any monitoring the engineer wants before, during, or after the work.

Respect the division of labor, and say it out loud to the owner so there is no confusion later. The engineer designs and takes responsibility for the structural design. You, the contractor, take responsibility for means, methods, workmanship, and executing the work as designed. Neither role replaces the other. I do not reline an engineer's detail in the field because it is inconvenient, and I do not ask an engineer to bless a shortcut I have already taken. If a detail cannot be built as drawn because of a hidden condition, I stop, photograph it, and ask for a revised detail. That conversation, documented, is professionalism. Silent substitution is how failures are born.

Ask questions until the detail is clear in your hands, not just

on paper. How much bearing, on what material, prepared how? What temporary support, in what sequence, removed when? What tolerances for level and plane? What should you watch for that would mean stopping and calling back? A pro is not embarrassed to ask. A pro is embarrassed only when he guesses on something load-bearing.

Finally, keep the engineer informed as the work opens up. Hidden conditions are normal on complex buildings. A quick photo set and a short call when the wall reveals something new protects the owner, the design, and your own record. Engineers remember contractors who bring them clean information early. Those are the contractors they recommend by name.

The Documentation an Engineer Actually Needs

An engineer cannot help you from a vague description and one blurry photo taken from the truck. Bring a package that respects their time and lets them see what you saw.

Start with context: full elevations of the wall, not just tight shots of damage, with the opening located in the building, the stories above and below identified, and north or a street reference noted so orientation is never in doubt. Add measured dimensions — opening width, lintel length and bearing at each end if visible, wall thickness if known, crack widths at their widest points, and the amount of deflection or out-of-plane movement measured against a straightedge or string line, with the tool visible in at least one photo for scale.

Add close documentation: each end bearing, the underside of the existing lintel, corrosion section loss, the condition of mortar and units directly above the opening, flashing and weep conditions, and any prior repairs in the same area. Photograph before you touch, as you open, and at each stage where a hidden condition appears. Date and label everything. An unlabeled photo folder of two hundred images is almost as unhelpful as no photos at all.

Add history, stated honestly as history: what the owner or manager reports about leaks, prior movement, additions, and earlier repairs, labeled as reported information, not as your verified finding. Add your own observations separately, in your own words: where you probed, what you found, what you did not open and therefore do not know. That honesty about the boundary of your knowledge is exactly what a good engineer values most in a field partner.

Close the package with your specific questions, listed one by one. An engineer who can see the building through your

documentation, and who knows precisely what decisions you need, can respond faster, charge the owner less for wandering, and give you a detail you can actually build. Knowing the line, and documenting up to it well, is not stepping back from the work. It is how complex work gets done right.

Chapter 11: Documenting, Bidding, and Defending Complex Work

Complex lintel work is sold twice. It is sold once before the job, when the owner agrees to a scope and a price, and it is sold again after the job, when someone — an owner, a property manager, a buyer, an insurer, or an engineer — asks what was actually done and why. Documentation is the bridge between those two moments. Without it, even excellent workmanship becomes a story no one can verify. With it, honest work defends itself.

In 50 years of Texas field work, I have learned that the contractors who get in trouble on complex buildings are rarely the ones with the least skill in their hands. They are the ones with the thinnest paper. They bid from memory, opened walls without photographs, agreed to changes in a hallway, and finished with an invoice that described three days of structural masonry work in one line. When a question came later, they had nothing to stand on but insistence. This chapter is the discipline that prevents that: forensic documentation, scopes that protect both sides, honest allowances for what no one can see yet, and pricing that tells the truth about risk.

Forensic Photo and Report Discipline

Treat every complex job as if a knowledgeable stranger will need to understand it a year from now, without you in the room. That stranger test shapes everything.

Photograph in a fixed sequence, the same way every time, so nothing depends on memory or mood. Start wide: the full building, the full elevation, the street and entry context. Move to the wall: the entire wall plane containing the opening, straight on and at an angle so out-of-plane movement reads clearly. Move to the opening: full opening, then each bearing end, then the lintel underside, then the masonry field above. Move in close: cracks with a ruler or crack gauge in frame, corrosion with a coin or tape for scale, mortar condition, flashing, weeps, and any water staining that explains how the failure got its start. Repeat the same angles after opening, after removal, after the new support is set, and after the

masonry is rebuilt and tooled. Before, during, and after, from the same viewpoints, is what turns photos into evidence instead of souvenirs.

Write the report while the building is still in front of you. A good field report is plain and separated into three parts that must never blur together: what was observed, what was measured, and what is recommended. Observed means what your eyes and hands verified — a rusted lintel flange thinned to a knife edge at midspan, hollow-sounding brick at the left bearing, a prior hard-cement repoint over softer original mortar. Measured means numbers with methods — opening width, deflection against a string line, crack width, bearing length exposed. Recommended means the work you propose, and where a structural engineer is involved, whose design governs which part. Keep reported history labeled as reported. "The manager reports a leak since 2019" is honest. Stating that leak history as your own verified fact, when you arrived this morning, is not.

Label files the day they are taken, back them up before you leave the site, and keep the job file together: photos, report, proposal, signed scope, engineer correspondence where applicable, change orders, and final photos in one place. On a disputed job, the contractor who can produce a dated, ordered file in ten minutes settles questions that drag for months for the contractor who cannot.

Composite example: On a multi-opening commercial facade, the crew photographed and labeled each opening separately — north elevation, opening three, left bearing, before removal — instead of pooling all images in one folder. When the owner later questioned whether a particular cracked bearing had been rebuilt or left as found, the dated sequence for that single opening answered the question in one viewing, with no argument and no ill will on either side.

Scopes That Protect Both Sides

A good scope is not a shield for the contractor. It is a clear agreement that protects the owner from surprise and the contractor from open-ended obligation, and it does both by being specific.

Name the work precisely: which openings, on which elevations, what is removed, what support system is installed — for lintel replacement work under the LintelLOCK approach, described plainly as a field-developed system built from decades of field practice — what masonry is rebuilt, what flashing and weep provisions are included, what mortar matching standard is expected, and how the finished plane and finish will be judged. Name what is not included with equal clarity: interior repairs, unrelated facade repointing,

foundation work, glass and frame work, painting, or repairs to openings not listed. Most disputes I have witnessed began not with bad work but with two honest people holding two different pictures of what "fix the front" included.

Write the hidden-conditions clause into every complex scope, in plain language the owner can understand before signing. Opening a wall on an older building can reveal deteriorated backup, damaged bearing, hidden steel, water damage, or prior alterations that no surface inspection could confirm. The clause should say that such conditions, when found, will be documented with photos, brought to the owner promptly, and addressed only under a written change order or a pre-agreed allowance procedure — never silently absorbed, and never silently billed after the fact.

State the standards and the limits honestly. Mortar color matching on weathered buildings is a best-effort craft outcome influenced by age, exposure, and original materials; say so. Existing out-of-plane conditions in surrounding masonry that the scope does not rebuild will remain; say so. Where an engineer's design governs, name that relationship. An owner who signs a scope that told the truth has very little to dispute later, and a contractor who wrote it has very little to fear.

Allowances for Hidden Conditions

On complex lintel work, pretending you can see through brick is the fastest way to lose money or lose trust — usually both, in that order. Allowances are how honest contractors price the unknown without guessing at it or gambling on it.

Use an allowance when a condition is likely, its exact extent is unknowable until opening, and the unit of repair is definable in advance. Rebuilding deteriorated bearing masonry beyond the exposed ends, replacing additional deteriorated backup units, or extending flashing repair beyond the opening are classic allowance items. Define each allowance with a unit — per opening, per bearing, per square foot of rebuilt backup — a unit price, and a not-to-exceed discussion held before work begins. Photograph the condition that triggers the allowance at the moment it is exposed, get the owner's or manager's acknowledgment in writing, and track allowance use on the invoice as its own line, with photos available on request.

Do not bury risk inside allowances that are really certainties. If you already know from probing that a bearing is gone, price it in the base scope and say why. Allowances used as a low-bid trick — a thin base price fattened later by predictable "surprises" — is a practice owners learn to smell, and property professionals talk to each other. The allowance is a tool for genuine unknowns, handled transparently. Used that

way, it lets you bid competitively on what you know and fairly on what no one yet knows, without asking either side to pretend.

Hypothetical example: A proposal carries the base lintel replacement at a fixed price, plus a stated allowance for rebuilding hidden backup deterioration at a named unit price, triggered only by photographed conditions and written acknowledgment. The wall opens clean on one opening and deteriorated on the next. The first allowance goes unused and is never billed. The second is documented, acknowledged, and billed at the agreed unit. The owner pays more on one opening and nothing extra on the other, and trusts the process on both — because the process was agreed before anyone saw inside the wall.

Pricing Complex Lintel Risk Honestly

Price the job you actually inspected, not the job you hope it turns out to be.

Complex work carries real cost drivers that simple per-opening pricing hides: access and protection on occupied buildings, shoring and sequencing, staged openings so a building is never left unsupported beyond the plan, engineer coordination, matching materials on older masonry, and the slower pace that careful forensic work demands. Name those drivers in your own estimating, even if the proposal summarizes them, so a low number never tempts you to recover margin by cutting the very steps that make the work safe and lasting.

Price risk where risk actually lives. A sound wall, a standard span, and straightforward access is one price conversation. The same span over an entry on a multi-story building with compromised bearing, active water entry, and deteriorated backup is another, and the difference is not padding — it is labor, material, protection, and responsibility that a professional can explain line by line. If an owner asks why your number is higher than a simpler bid, the answer is the documented condition of their building, walked through photo by photo. Contractors who can explain a price from evidence rarely need to defend it from suspicion.

Hold change-order honesty as a hard line. No change without documentation, no documentation after the fact, no verbal extras folded quietly into a final invoice. When a hidden condition appears, stop that portion of work, photograph it, price it, get written approval, then proceed. When you make an error — a mismeasured unit, a damaged finish, a delay that is yours — own it in writing and absorb what is yours to absorb. That single habit, repeated over years, builds the kind of reputation among property professionals that no

advertising can buy. Complex work is defended the same way it is won: with a clean file, a clear scope, and a price that told the truth from the first day.

Chapter 12: Failure Autopsies — Patterns Pros Learn to Prevent

Every failed lintel I have ever removed taught a lesson that was available before the failure, usually for free, in the form of a small sign someone walked past. Failure autopsies are how pros collect those lessons without having to pay full tuition on their own jobs. You study the pattern — water, load, bearing, material, workmanship, maintenance — until the early signs become as familiar as faces.

The cases in this chapter are composite and hypothetical teaching cases, built from patterns that repeat across Texas buildings. They are not accounts of specific customers or specific addresses, and no real property should be recognized in them. Read each one the same way: what failed, what allowed it to fail, what the early sign was, and what a professional does differently on the next building that shows that sign.

Autopsy One and Two: Water Did the Work, Steel Took the Blame

Composite example: The sagging storefront. A ground-floor commercial opening develops a visible sag at midspan, cracked mortar joints stepping up from both top corners, and rust staining bleeding down the face below the lintel line. Removal reveals a lintel whose bottom flange has lost much of its thickness to corrosion, worst at the center third. The easy story is "the steel wore out." The autopsy tells the truer story: flashing above the opening was discontinuous, weeps were blocked by a later repoint that sealed the bottom joint solid, and water entering the wall from a failed parapet cap above had nowhere to go except onto the steel, where it sat for years. The lintel did not fail first. The water management failed first, and the lintel was simply the part that paid for it in public. Prevention: on every lintel assessment, trace the water before you judge the steel. Cap, flashing, weeps, and the joints above the opening are part of the lintel system, and a replacement installed under the same unmanaged water path is a replacement scheduled to fail on the same timetable.

Hypothetical example: The garage that rusted from the inside. A residential garage lintel looks sound from the street except for a hairline crack and a faint stain, but tapping along the underside gives a hollow, flaky answer over most of its length. The wall cavity had been collecting condensation and leak

water against unprotected steel, and corrosion expanded inside the section, quietly cracking the masonry it carried from within. Expansive rust can exert enormous pressure — the steel grows as it corrodes, lifting and splitting the very masonry it supports, which is why early rust-jacking cracks parallel to a lintel should never be dismissed as cosmetic. Prevention: probe the underside, not just the face; treat staining plus a parallel crack as a corrosion investigation, not a caulking job; and when you replace, protect the new steel and restore the drainage path so the cavity stops feeding the failure.

The shared lesson of both cases deserves its own line: sealing the visible crack while leaving the water source untouched is the most common false repair in this trade. It makes the wall look cared for while the mechanism of failure continues, hidden, at full strength.

Autopsy Three and Four: Bearing and Deflection, the Quiet Partners

Composite example: The new lintel on old ends. A replacement lintel, sound and correctly sized, is set on the original bearing at both ends without rebuilding them. Within a few seasons, cracking returns — not at midspan this time, but crushing and stepping at one end, where the bearing brick, already deteriorated behind the face, slowly gives way under concentrated load. The autopsy is uncomfortable because the headline work was done well. The failure lived at the interface no one renewed. Bearing is not a detail at the edge of the job. It is half the job. Prevention: expose, assess, and rebuild bearing as a named scope item on every complex replacement; photograph the bearing you land on; and where bearing material is doubtful and the load is significant, that is a referral-threshold condition under the rules of Chapter 10, not a judgment to bury inside a wall.

Hypothetical example: The wide opening that moved a little, then a lot. A wide opening is fitted with a support that is adequate in strength but limber in service, and the masonry above it is rebuilt before any deflection under load has settled. Hairline cracking appears at the corners almost immediately and is pointed up as settlement. It reopens. It is pointed again, harder, and the harder mortar concentrates stress until units themselves begin to crack. The pattern here is a serviceability failure wearing the disguise of a maintenance nuisance. Masonry is stiff and unforgiving of movement; a support that bends noticeably under the load it carries will keep announcing that fact through the wall above it, no matter how many times the announcement is repointed. Prevention: respect deflection as a design-level concern on wide spans, coordinate sizing with a structural engineer

where the span or load calls for it, sequence the rebuild so the support is carrying before the masonry above is completed, and never chase recurring corner cracks with harder mortar as a substitute for understanding why the opening is moving.

Autopsy Five and Six: Mortar, Movement, and the Repair That Fought the Building

Composite example: The hard patch on a soft wall. An older building built with soft brick and lime-rich mortar is repointed in patches with a hard, dense modern mortar by a well-meaning crew. The patches look sharp for a year. Then the brick faces around them begin to spall, edges crumble, and moisture that once passed harmlessly through the soft joints is now trapped and driven through the units themselves, where freeze and salt action break them from inside. Above openings, where movement concentrates, the hard joints crack the units instead of flexing with the wall. The autopsy lesson is a materials law: a repair mortar must be compatible with, and never harder than, the masonry system it joins. Strength in the bag is not strength in the wall. Prevention: identify the original mortar character before specifying its replacement — this is core MortarMagic discipline, matching color, composition, and behavior together — and treat any older, softer wall as a compatibility problem first and a pointing job second.

Hypothetical example: The crack that was a joint doing its job. A long wall with no functioning movement joints telegraphs its seasonal stress to the weakest points — the corners of its openings — where cracking recurs on a yearly rhythm, opening in one season and closing in another. Successive repairs treat each opening as an isolated lintel problem until a wider reading of the building shows the wall itself has nowhere to move. The lintels were carrying the blame for a wall-length movement problem. Texas heat, sun-driven expansion on long elevations, and clay soil movement cycles make this pattern common enough that every pro should test for it before condemning hardware. Prevention: read the whole elevation before pricing the single opening, distinguish live seasonal cracks from progressive failure by their pattern and rhythm, document that distinction for the owner, and scope the actual mechanism — which may involve joint work, monitoring, a foundation evaluation where soil movement is implicated, or an engineer referral — rather than repeatedly replacing sound supports under a moving wall.

The Prevention Checklist Pros Carry Forward

Close every autopsy by converting it into a check you will

actually perform, or the study was just storytelling. These are the checks these patterns produce, stated plainly enough to use on a ladder.

One, trace the water to its source and its exit before judging any steel: caps, flashing, weeps, joints, and staining, in that order, on every assessment. Two, probe the steel you cannot see — underside, ends, and section loss — and treat staining with a parallel crack as corrosion until proven otherwise. Three, expose and judge bearing at both ends as a primary scope item, and rebuild or refer wherever bearing is doubtful under real load. Four, respect span and deflection: wide openings and heavy loads get design-level attention, correct sequencing, and no cosmetic chasing of movement cracks. Five, match mortar to the wall that exists — never harder than the system it repairs — and match color and behavior as one decision, not two. Six, read the whole elevation and the whole building before condemning a single opening: movement joints, parapets, foundation lines, and prior alterations all testify. Seven, photograph and label in a fixed sequence so the next professional — or the same professional, a year later — can autopsy your work and find it sound. Eight, know the line from Chapter 10 and honor it early: active movement, multi-story patterns, life-safety signs, and unexplained load paths get a licensed structural engineer, promptly and without apology.

No building fails all at once. It fails in a sequence of small, readable events, most of them announced in advance to anyone trained to look. The professional advantage is not stronger hands. It is earlier reading, honest documentation, and the discipline to fix causes instead of faces. Learn these patterns here, on paper, and you will recognize them out there, on brick, while they are still cheap to correct.

One final habit ties all six autopsies together: revisit your own finished work when you have the chance. Drive past a complex job a year later, and five years later, and read it again with the same forensic eyes you would turn on a stranger's failure. Are the joints sound? Is the staining absent? Are the corners quiet? Pros who schedule that kind of honest revisit learn faster than pros who only ever study other people's mistakes, because their own buildings become their continuing education. Keep notes from those revisits in the job file, beside the original photos, so the comparison is documented rather than remembered fondly. A trade that studies itself this way gets safer, steadier, and harder to fool with every passing season.

Conclusion: Carry It Right, and It Carries for Good

A lintel is a promise a building makes at its most vulnerable place. Every opening interrupts the wall, and something has to carry the load across that interruption, quietly, in all weather, for longer than any of us will stand in front of it. When that carrying is done right, nobody notices. Doors swing true. Windows sit square. The brick above an entry does its work decade after decade without asking for attention. That invisibility is the reward of this trade, and it is earned entirely in the moments when cutting a corner would have been easy and no one was watching.

Across this book, the same principles kept returning, because on real buildings they are the only principles there are. Read the load path before you touch the support, all the way to the ground. Trace the water before you judge the steel, because water writes most failure stories and steel merely signs them. Respect bearing as half the job. Match your materials to the wall that exists, not the wall you wish existed. Document what you found, what you measured, and what you did, in a file that could defend your work to a stranger a year from now. Price the risk honestly, handle the hidden conditions in the open, and know the line where field experience calls in a licensed structural engineer — and honor that line early, as a professional, every time.

None of that requires genius. It requires discipline on ordinary days, on hot days, on the days when the owner is pressing for a lower number and the wall is pressing back with surprises. The buildings that fail early were rarely failed by a single dramatic error. They were failed by small surrenders: the flashing left discontinuous because the scaffold was already up, the bearing left unexamined because the steel was already on the truck, the crack sealed because the water question was inconvenient. Carry it right means refusing those surrenders, one decision at a time, until refusal is simply your habit.

It also means remembering what the work is for. Above every opening is a load, but below it are people — families moving through a garage door a thousand times a year, customers under a storefront, tenants under floors they trust without thinking. Our trade holds up the literal weight over their heads. That is worth doing carefully, worth documenting honestly, and worth handing to the next generation of masons in better shape than we found it. Fifty years in Texas brick and masonry have taught me that a reputation is just a long record of openings that never made the news.

So take the checklists, the autopsies, and the thresholds in this book out onto real elevations and use them until they are reflex. Photograph before you touch. Measure what others estimate. Ask the engineer before you need rescuing. Write the scope you would want to sign as an owner. And when the

wall opens and shows you something you did not expect, treat it as the building telling you the truth at last — then answer it with the best work you know how to do.

There is also a duty to the people coming up behind you in this trade. The young mason on your crew is learning more from what you tolerate than from what you say. If you stop for the engineer when the signs call for it, document when it would be faster not to, and rebuild a doubtful bearing when no one would have known the difference, that young mason learns what professional actually means. If you do the opposite, that lesson is taught just as thoroughly, in the other direction. Complex work is where the next generation decides whether this trade is a craft with standards or just a race to the invoice. Teach it as a craft.

And there is a plain business truth underneath all the craft talk in this book: doing it right is the durable way to make a living at it. Owners and property professionals remember who told them the truth about a hidden condition, who priced a risk honestly and then honored that price, and whose work still looks sound when the next contractor photographs it years later for a different project. That memory is worth more than any single job won by a thin bid and defended with thin paper. The work compounds. So does the reputation, in whichever direction you build it.

So this book closes where it opened: above the opening, with weight to carry and a choice about how to carry it. Make the choice that lets the building, the people under it, and the professional who did the work all stand straight for a long time.

Carry it right, and it carries for good.

Resources & Next Steps

If a building in your care is showing the signs this book describes — sagging or rust-stained lintels, stepping cracks above openings, loose or bowing masonry, water entry at the wall, or movement you cannot explain — the next step is a documented, professional assessment before the pattern gets more expensive or less safe. Start with the team whose field work this book is built on:

Travis Nech has spent 50 years in brick, masonry, and foundation work across Texas. He owns and operates Champion Brick Repair, Metro Foundation Repair, LintelLOCK, MortarMagic, and WhiteStone Construction.

- **Champion Brick Repair** — brick & masonry repair, Dallas-Fort Worth —

[championbrickrepair.com](<https://championbrickrepair.com>) — (817) 900-6324

- **Metro Foundation Repair** — pressed concrete pile foundation repair — [metrofoundationrepair.com](<https://metrofoundationrepair.com>) — (817) 523-1540
- **LintelLOCK** — the field-developed lintel replacement system — [lintlerepair.com](<https://lintlerepair.com>) — (469) 730-0650
- **MortarMagic** — mortar color matching & the Mortar Bucket — [mortarmagic.netlify.app](<https://mortarmagic.netlify.app>)
- **WhiteStone Construction** — stone, ranch & property work, Hamilton TX country — (254) 723-5040

For lintel concerns specifically, reach the LintelLOCK team through lintlerepair.com or (469) 730-0650. For brick and masonry repair across Dallas-Fort Worth, contact Champion Brick Repair. For foundation evaluation involving pressed concrete piles, contact Metro Foundation Repair. Bring your photos, your measurements, and your questions — that is exactly the kind of start this book has tried to teach.

About the Author

Travis Nech has spent 50 years with his hands in Texas masonry — as a working mason first, and then as the owner-operator who still reads walls the way he learned to read them on his earliest jobs: by looking carefully, measuring honestly, and respecting what the building is trying to say. The work has taken him from single-family brick repairs to complex multi-opening commercial buildings across Dallas-Fort Worth and the Hamilton County country he calls home ground.

Over those decades he built five working brands, each one answering a specific need he kept meeting in the field: Champion Brick Repair for brick and masonry repair, Metro Foundation Repair for foundation repair using pressed concrete piles, LintelLOCK as his field-developed system for lintel replacement, MortarMagic for mortar color matching and the Mortar Bucket, and WhiteStone Construction for stone, ranch, and property work. The brands are separate because the problems are separate, but the standard across all of them is the same standard this book teaches: document it, carry the load honestly, and know the line where a job calls for a licensed structural engineer.

He wrote this book for the experienced pros and property professionals who carry the same responsibility he does — the weight over other people's doorways — and who want that work to outlast them. His authority on the subject is the

authority of the field itself: 50 years of openings assessed, lintels replaced, bearings rebuilt, and lessons collected, including the ones the failed work taught.

Travis Nech has spent 50 years in brick, masonry, and foundation work across Texas. He owns and operates Champion Brick Repair, Metro Foundation Repair, LintelLOCK, MortarMagic, and WhiteStone Construction.

- **Champion Brick Repair** — brick & masonry repair, Dallas-Fort Worth — championbrickrepair.com — (817) 900-6324
- **Metro Foundation Repair** — pressed concrete pile foundation repair — metrofoundationrepair.com — (817) 523-1540
- **LintelLOCK** — the field-developed lintel replacement system — lintlerepair.com — (469) 730-0650
- **MortarMagic** — mortar color matching & the Mortar Bucket — mortarmagic.netlify.app
- **WhiteStone Construction** — stone, ranch & property work, Hamilton TX country — (254) 723-5040